

BIGBEN
396 - 466 rue de la Voyette
CRT2 59273 FRETIN
FRANCE
Powerbank for Nintendo Switch™
SWITCHRACKETS
Model No. : BB3160
Made in China



BIGBEN

Набор игровых теннисных ракеток для Joy-Con Nintendo Switch



**Руководство по эксплуатации
/ User guide**

www.nacongaming.com

Recommendations for use

Please read this manual carefully before using your rackets kit.

1. Insert the Joy-Con into the notch provided for this purpose.
2. Make sure the Joy-Con is pushed in fully so that it's in contact with the bottom of the housing recess.
3. Then attach the safety strap to your wrist.
4. Adjust the wrist strap so that it fits your wrist lightly and snugly.

Safety precautions

1. This product is only to be used indoors
2. Do not expose it to dust, direct sunshine, high humidity, heat or mechanical impact
3. Do not expose it to humidity or any liquid product or mould
4. Do not immerse in liquid
5. Do not use this product if damaged
6. For cleaning, be sure to remove the Joy-Con, use a soft, clean, slightly damp cloth, and do not use solvents as they can degrade the product.
7. Never hold this product by the strap; always hold the product by the handle provided for this purpose.
8. Make sure you have a sufficiently clear play area; if you're playing with a second person, make sure you keep a sufficient distance from each other to avoid contact.

Any misuse of this product or non-compliance with the instructions for placing the Joy-Con in the racket causing discomfort or damage cannot be covered by the warranty.

This product is not designed for people (including children) suffering from a physical, sensory or mental handicap, or for users without the necessary relevant experience or knowledge (unless they have been given advice and instructions on how to use the device from a person responsible for the user beforehand). Do not leave the product unattended, do not leave this product within the reach of children. Not suitable for children under 7 (the cable can get wrapped around their neck). Children must not clean or maintain the device without supervision.

Health recommendations

If at any time while using this product you experience pain or numbness in your hands, wrists, elbows or shoulders, we recommend that you stop using this product until the symptoms resolve.

We recommend you take regular breaks of 15 minutes every hour.

TECHNICAL HELPLINE INFORMATION

The Technical Helpline is a live one-to-one service

Support contact: support@ncongaming.com

UK: 0905 710 0015

Hours: 10:00am till 5:00pm, Monday to Friday

(All calls are charged at 30 pence per minute. All callers must be over 16 years of age. Permission must be obtained from the person paying the bill. Parental supervision is recommended).

Eire: 154 056 3001

Hours: 10:00am till 5:00pm, Monday to Friday

(All calls are charged at 60 euro cents per minute. All callers must be over 16 years of age. Permission must be obtained from the person paying the bill. Parental supervision is recommended).

To ensure that your call is handled quickly and effectively please ensure that you have the model number and any other relevant information regarding your product. Calls may be recorded for training purposes.

Внимательно ознакомьтесь с руководством перед эксплуатацией!

1. Вставьте Joy-Con в соответствующий разъем.
2. Убедитесь, что Joy-Con полностью вставлен так, чтобы он соприкасался с нижней частью углубления в корпусе.
3. Затем прикрепите ремешок безопасности к запястью.
4. Отрегулируйте ремешок на запястье так, чтобы он легко и плотно облегал запястье

Меры предосторожности:

1. Использовать ракетки только в помещении
2. Не подвергать их воздействию пыли, прямых солнечных лучей, высокой влажности, тепла или механических воздействий.
3. Не подвергайте их воздействию влаги или каких-либо жидких продуктов или плесени.
4. Не используйте ракетки, если они повреждены.
5. Не держите ракетки за ремешок; всегда держите ракетки за ручки.
6. Для очистки, извлеките Joy-Con, используйте мягкую сухую ткань.
7. Убедитесь, что у вас есть достаточно чистая игровая площадка; если вы играете со вторым человеком, убедитесь, что вы держитесь на достаточном расстоянии друг от друга, чтобы избежать контакта.

Любое неправильное использование этого продукта или несоблюдение инструкций по размещению Joy-Con в ракетке, вызывающее дискомфорт или повреждение, не покрывается гарантией.

Этот продукт не предназначен для людей, страдающих физическими, сенсорными или умственными недостатками, или для пользователей без необходимого соответствующего опыта или знаний (если только они не получили совет и инструкции по использованию устройства от лица, который пользовался ранее). Храните ракетки в недоступном для детей месте. Не подходит для детей до 7 лет.

Если во время использования этого продукта вы испытываете боль или онемение в руках, запястьях, локтях или плечах, мы рекомендуем вам прекратить использование этого продукта до исчезновения симптомов.

Рекомендуется делать перерывы на 15 минут каждый час использования.

Техническая поддержка:

Почта: support@nacongaming.com

Сайт: www.nacongaming.com