68

105

英语

SOOCAS

User Manual

Safety precautions are particularly important! Please take your time to read it through.

Warnings
1. This product is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are supervised or given instruction concerning use of the product by an adult responsible for their safety.
2. It is forbidden to recharge the product in a humid environment.
3. Do not use the product in a humid environment.
4. Users of orthodontics, dental repair, dental implants, etc. should use this product with caution and consult a dentist.
5. This product complies with the safety standards of electromagnetic radiation. If you have a medical implant, please consult a doctor or the manufacturer of your medical implant before using this product.
6. This product is only designed for a non-tooth gum and tongue. Do not use it on other parts of the body. Please stop using it if you feel any side-effects and contact your dentist.
7. Do not use the charger provided with this product with a dedicated charging hub or a dedicated consumer accessoryof from its manufacturer. Do not use it for other purposes.
8. Before charging, please ensure that the charging port of the product is dry.
9. Do not use charging ports on other electronic equipment. The incorrect charging method may cause a fire.

Caution
1. Please charge the product for the first few days, your mouth may feel tender and gum may bleed. Increase your gum and tongue health gradually to only sensitive needles caused by high-frequency cleaning. If the bleeding or other discomfort persists, please stop using the product and consult a dentist.
2. This product contains a built-in rechargeable battery. Do not throw it into the fire, heat up, cut and recharge, use or store it at a high temperature environment.
3. Please recycle the product or dispose of it in accordance with local laws.
4. Do not use or clean your toothbrush while taking a bath or shower.

Each Component Demonstrates Our Professional Attitude and Supervised Design

Toothbrush Handle
Transparent Shell
User Manual
Charging Base
Toothbrush Head for Gum Massage
On/Off Button (On/Off & Mode Selection)
Mode Indicator (Gentle Mode)
Mode Indicator (Cleaning Mode)
Mode Indicator (Whitening Mode)
Mode Indicator (Polishing Mode)
Battery Indicator (Red Slower Indicator)
Toothbrush Handle
Wall Hanger (Suction Cup Installed)
Atmosphere Light Ring
Type-C Charging Port
Charging Contact Point
Charging Base
Product Name: SOOCAS All-Care Sonic Electric Toothbrush
Product Model: D3
Rated Input: 5V⎓ 1A
Charging Time: about 4 hours
Charging Method: Type-C charging
Product Name: SOOCAS All-Care Sonic Toothbrush Sanitizer
Model: D3
Rated Input: 5V⎓2.1A
Charging Time: about 3 hours
Charging Method: Type-C charging
Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

Even If a Toothbrush Head Can Only Be Used For Three Months, It Should Be Kept as Good as New Each Day

Important
Before using the product, check whether there is any obvious damage. Do not use it if it is damaged or suspected that there is damage. Please contact the manufacturer for inquiry.
1. Before cordwinding the power supply, please check whether the local power supply voltage is consistent with the rated voltage of the product.
2. It is forbidden to recharge the product in a humid environment.
3. Do not use the product in a humid environment.
4. Users of orthodontics, dental repair, dental implants, etc. should use this product with caution and consult a dentist.
5. This product complies with the safety standards of electromagnetic radiation. If you have a medical implant, please consult a doctor or the manufacturer of your medical implant before using this product.
6. This product is only designed for a non-tooth gum and tongue. Do not use it on other parts of the body. Please stop using it if you feel any side-effects and contact your dentist.
7. Do not use the charger provided with this product with a dedicated charging hub or a dedicated consumer accessoryof from its manufacturer. Do not use it for other purposes.
8. Before charging, please ensure that the charging port of the product is dry.
9. Do not use charging ports on other electronic equipment. The incorrect charging method may cause a fire.

Caution
1. Please charge the product for the first few days, your mouth may feel tender and gum may bleed. Increase your gum and tongue health gradually to only sensitive needles caused by high-frequency cleaning. If the bleeding or other discomfort persists, please stop using the product and consult a dentist.
2. This product contains a built-in rechargeable battery. Do not throw it into the fire, heat up, cut and recharge, use or store it at a high temperature environment.
3. Please recycle the product or dispose of it in accordance with local laws.
4. Do not use or clean your toothbrush while taking a bath or shower.

Product Name: SOOCAS All-Care Sonic Electric Toothbrush
Product Model: D3
Rated Input: 5V⎓ 1A
Charging Time: about 4 hours
Charging Method: Type-C charging
Product Name: SOOCAS All-Care Sonic Toothbrush Sanitizer
Model: D3
Rated Input: 5V⎓2.1A
Charging Time: about 3 hours
Charging Method: Type-C charging
Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

Brand-new Electric Toothbrush User Experience: One More Procedure Provides More Oral Care

Take Out and Install the Toothbrush Head
The toothbrush head base has been installed in the factory. Simply remove secure packaging. Align the toothbrush head with the charging hub, insert the transparent shell into the charging base, and gently press the toothbrush head. If you hear a "click" sound, it indicates that the installation is successful.

Enjoy Brushing Your Teeth
In fact, you just need to simply turn on the toothbrush and start brushing your teeth. The device will automatically recognize your brushing habits and Smart Mode Selection function to select the most suitable cleaning mode for your teeth and achieve efficient cleaning. The toothbrush head will also gently massage teeth without causing a taste and discomfort.

The Sanitizer Will Run Automatically Every 7 Time the Lid is Closed
After brushing, lunch time, nap time, and bedtime, simply place the toothbrush head into the sanitizer and close the lid. The sanitizer will automatically sterilize the toothbrush head, ensuring the bristles remain clean and hygienic. The sanitizer also doubles as a charging base, ensuring your toothbrush is always ready for use.

With 4 Modes Available, You Can Choose What You Love. With Mode Memory Function, It Will Remember Your Brushing Preference.

Mode Memory Function
The toothbrush will remember the last mode you used, so you don't have to manually adjust it each time.

◇ Gentle Mode
Providing more gentle dental care, it is suitable for people who are sensitive to the first time, or people who have another preference.

◇ Cleaning Mode
Providing basic gentle dental care, it is suitable for people who are used to the cleaning mode of other toothbrushes, or people who have sensitive teeth or gingival inflammation.

◇ Whitening Mode
The carefully calibrated Whitening Mode is designed to provide a gentle massage of sensitive teeth while effectively removing stains and achieving effects in 2 weeks.

◇ Polishing Mode
The Polishing Mode frequency alternating direction is not gentle and brighten the surface of teeth while offering deep cleaning. It is specifically used for tobacco, tea and coffee.

SOOCAS

Mode Memory Function
Gentle Mode
Cleaning Mode
Whitening Mode
Polishing Mode

Clean the Wall Hanger
After each use, clean the wall hanger to keep it clean and dry. The suction cup is installed on a smooth wall flat surface and is secured. Do not place it on a rough wall surface. Do not place it in a humid and high-temperature environment and avoid direct sunlight.

Paste the Wall Hanger
Pull the wall hanger base from the back of the hanger and remove the silicone protective film on the back. Align the wall hanger with the desired position, press it firmly against the wall surface, and wait for 24 hours. To ensure the adhesive effect, do not place the wall hanger in a humid environment, avoid pasting and pressing the wall hanger deep in the AC ducts, and install the wall hanger.

Installation & Use
1. Place the wall hanger on the wall, hang the hanging hole on the hook of the wall hanger, and gently pull the wall hanger to the left or right to ensure that the wall hanger is firmly hung on the hook. Place the toothbrush handle and place the hanging and pasting the wall hanger deep in the AC ducts, and install the wall hanger.

Notes
- Do not paste the wall hanger on any ordinary wall that has peeling paint, powder, or is not smooth and flat.
- Do not remove the adhesive for secondary pasting. In order to avoid damage to the wall, do not reuse it.
- Do not place the wall hanger in a humid or high-temperature environment, avoid direct sunlight, and do not place it in the AC ducts, ventilation ducts, or other areas that may affect the suction cup effect.

As elegant as a Guardian, the Sanitizer Should Be Recharged Every Month.

Power On Status
After turning the toothbrush on for 10 seconds, you can press the On/Off button to switch modes. When in standby mode, you can press and hold the On/Off button for 3 seconds to shut down.

Pause Status
After turning the toothbrush on for 10 seconds, you can press the On/Off button to pause the toothbrush. The toothbrush will automatically turn off after the battery indicator will flashes for 30 seconds.

Charging Reminder
When you find that the toothbrush's battery indicator flashes red, it indicates that the toothbrush's battery is low and requires timely charging to ensure its smooth.

Charging Reminder
The battery indicator will flashes slowly during charging.
When the battery level is less than 80%, the battery indicator will flash green slowly.
When the battery level reaches 80%, the battery indicator will turn green and stay. Indicating that the battery is fully charged.

SOOCAS

Power On Status
Pause Status
Charging Reminder

In addition to convenient type-C charging, the long battery life of electric toothbrush will bring more convenience and ease.

Out-of-the-Box Service
Enjoy the convenient and hygienic Out-of-the-Box Service and toothbrush order routing, water jet check, no toothpaste residue remaining. And you should remove the toothbrush head every few days for hygiene and safety.

Indicator Reminders
Working Status: The sanitizer's atmosphere indicator will turn on for 5 minutes, and the lid will be opened flashing for 5 seconds.
Power Emergency: when entering the sterilization status, the atmosphere indicator light will flash slowly for 1 seconds and then turn off. The sanitizer will automatically exit the sterilization status.
Out of Battery: The atmosphere indicator will battery level indicator flash quickly and then go out.
Damage Alarm: If the coil, sterilizing lamp is damaged and lower than the minimum voltage, the battery level indicator will flash red slowly, and the battery level indicator will flash for 3 seconds and then turn off. Please contact us in time for after-sales support.

Universal Port for Fast Charging
The sanitizer supports fast charging, ensuring efficient charging and convenient use. It uses the Type-C port, which is universal and compatible with the standard charging port. Convenient and fast charging can be completed in about 5 hours.

Important Safeguard
To ensure good charging performance, please ensure that the charging and sterilization ports are dry before use. Do not use other charging ports or other electronic equipment to charge the sanitizer, as it may cause fire. Your safety is our top priority!

Being used in the morning and evening, the sanitizer can last for 30 days.
The sanitizer will satisfy the toothbrush head after you brush your teeth. It can be used continuously for about 30 days after its battery capacity for your convenience.

Ultra-long Battery Life
Thanks to the high-capacity battery, the toothbrush can be used for about 180 days after being fully charged. The battery life may differ under different modes and intensities.

Symmetry Design for Fast Charging
The toothbrush adopts a type-C high-efficiency charging port. When the charging port is inserted, it can be charged in any direction. It can be charged with the standard charging port. Convenient and fast charging can be completed in about 5 hours.

Out-of-the-Box Service
Enjoy the convenient and hygienic Out-of-the-Box Service and toothbrush order routing, water jet check, no toothpaste residue remaining. And you should remove the toothbrush head every few days for hygiene and safety.

Indicator Reminders
Working Status: The sanitizer's atmosphere indicator will turn on for 5 minutes, and the lid will be opened flashing for 5 seconds.
Power Emergency: when entering the sterilization status, the atmosphere indicator light will flash slowly for 1 seconds and then turn off. The sanitizer will automatically exit the sterilization status.
Out of Battery: The atmosphere indicator will battery level indicator flash quickly and then go out.
Damage Alarm: If the coil, sterilizing lamp is damaged and lower than the minimum voltage, the battery level indicator will flash red slowly, and the battery level indicator will flash for 3 seconds and then turn off. Please contact us in time for after-sales support.

Universal Port for Fast Charging
The sanitizer supports fast charging, ensuring efficient charging and convenient use. It uses the Type-C port, which is universal and compatible with the standard charging port. Convenient and fast charging can be completed in about 5 hours.

Important Safeguard
To ensure good charging performance, please ensure that the charging and sterilization ports are dry before use. Do not use other charging ports or other electronic equipment to charge the sanitizer, as it may cause fire. Your safety is our top priority!

Cleaning and Maintenance of Toothbrush and Sanitizer Daily Cleaning For Long Service Life

Rinse the Toothbrush After Use
After each use, remove the toothbrush head and sanitizer and toothbrush order routing, water jet check, no toothpaste residue remaining. And you should remove the toothbrush head every few days for hygiene and safety.
* It is recommended to change your toothbrush head within 3 months. If the bristles are flared, please replace it with a new toothbrush head in time.

Hang the Toothbrush in the Sanitizer after Rinsing
After rinsing the toothbrush, remove residual water drops and place its surface upwards in a towel or soft cloth. Then hang the toothbrush into the sanitizer. Increase hanging is can prevent the bottom of handle from being soaked in water.

Portable Toothbrush
If you need to take the electric toothbrush out, please remove the toothbrush head and place it in a dry bag. Do not place it in a humid environment. Do not place it in a humid environment or interior charging adapters to charge the product.

Wipe and Clean the Sanitizer
The sanitizer is designed for household use. It is recommended to wipe the surface with a damp towel. If the sanitizer is used for long maintenance, you can only clean the sanitizer, and should never clean it with water!

Warm Tips
If you think that the toothpaste is spread unevenly by the toothbrush, you can manually apply the toothpaste evenly on the bristle surface of each section before using the electric toothbrush.

The Standard Basic Method of Toothbrushing for Electric Toothbrushes, The Initial Matter of Brushing Teeth May Be Beyond Your Imagination

Place the bristles against the teeth
Place the bristles at a 45° angle to the gum line and gently massage the gum.

Horizontal brushing in a short-distance range
Gently moving the toothbrush back and forth in a short-distance range, ensuring that the bristles are not exerting pressure. Do not use a hard push and soft pull force; gently push the toothbrush forward and pull it back with a light force. Do not use a hard push and soft pull force.

Short-distance horizontal brushing

Divide your mouth into 4 sections
Divide your mouth into 4 sections. Brush the teeth in each area for at least 30 seconds, and the total time for 120 seconds. The brushing action will pause between each 30 second interval, and the toothbrush will vibrate to remind you. The toothbrush will automatically stop after 2 minutes of use.

Every Product Has Its Service Life. Please Recycle the Battery of the Product In Due Time!

Environmental Protection
Please recycle the product responsibly. According to the laws and regulations of the country or region where it is located, the several batteries in the product are not allowed to be disposed of as ordinary household waste. If you cannot take out the battery, please send the product to the nearest recycling point or to the manufacturer for recycling. Professional disassemblers (designated by the company, which will be responsible and bear the battery.

Warnings
1. Do not damage the battery while the tool is in use, and frequently replace or remove it every and harmful substances.
2. Do not short-circuit the battery, or connect it to a power source.
3. Do not use the disassembled, pierced, or even disassembled by yourself. Prevent pin disassembly will damage the product, leads safety hazards, and even causes fire and explosion. Do not use the damaged or crushed the disassembled battery. Incorrect recycling.
4. Do not expose the battery to high temperatures. If the battery is discharged, if you notice no out-of-the battery, you can turn it on until it turns off automatically.

Method of Removing Toothbrush Battery:

Method of Removing Sanitizer Battery:

Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

俄语

Руководство пользователя

Электрическая зубная щетка SOOCAS All-Care Sonic D3

Перед использованием обязательно прочтите, это важно!

Предупреждение
1. Данный продукт не предназначен для использования людьми (включая детей) с ограниченными физическими, сенсорными или умственными способностями, а также с недостаточным опытом и знаниями, если они не контролируются или не получают инструкции по использованию продукта от ответственного за их безопасность лица.
2. Запрещается заряжать изделие на влажной среде.
3. Запрещается использовать изделие на влажной среде.
4. Пользователям, занимающимся ортодонтией, реставрацией зубов, имплантацией зубов и т. д. следует использовать изделие с осторожностью и проконсультироваться с стоматологом.
5. Данное изделие соответствует стандартам безопасности электромагнитного излучения. При наличии проблемы, связанной с имплантатом, перед использованием изделия проконсультируйтесь с врачом или производителем медицинского имплантата.
6. Данное изделие предназначено только для чистки зубов, десен и языка. Не используйте его на других частях тела. Если вы почувствуете дискомфорт, прекратите использование и обратитесь к стоматологу.
7. Если используете зарядное устройство, поставляемое вместе с данным изделием, не подключайте к концентратору или специализированным аксессуарам, предназначенным для потребителей, производителя. Не используйте для других целей.
8. Перед зарядкой убедитесь, что зарядный порт изделия сухой.
9. Не используйте зарядные порты на другом электронном оборудовании. Неправильная зарядка может привести к пожару.

Внимание
1. При использовании этого продукта в течение первых нескольких дней ваши ротовая полость и рот или кровоточить, ваши ротовая полость и язык еще не адаптировались к этой высокочастотной чистке, и вы можете почувствовать только иголки. Если кровотечение или другие неудобства не исчезнут, прекратите использование и обратитесь к стоматологу.
2. Данный продукт содержит встроенную перезаряжаемую батарею. Запрещается бросать ее в огонь, нагревать, резать, заряжать или хранить при высокотемпературе.
3. Утилизируйте изделие или сдайте его в соответствующие пункты сбора, в соответствии с законодательством страны или региона.
4. Не пользуйтесь и не чистите зубную щетку во время принятия ванны или душа.

Каждый компонент имеет следующие профессиональные отношения и обеспечивает более высокий уровень ухода за полостью рта, чем обычная зубная щетка.

Корпус зубной щетки
Прозрачная оболочка
Руководство пользователя
Зарядная подставка
Насадка для массажа дёсен
Кнопка вкл/выкл (вкл/выкл & выбор режима)
Индикатор режима (Нежный режим)
Индикатор режима (Режим чистки)
Индикатор режима (Режим отбеливания)
Индикатор режима (Режим полировки)
Индикатор заряда батареи (медленный красный индикатор)
Корпус зубной щетки
Атмосферное кольцо
Порт зарядки Type-C
Контакты для зарядки
Зарядная подставка
Product Name: SOOCAS All-Care Sonic Electric Toothbrush
Product Model: D3
Rated Input: 5V⎓ 1A
Charging Time: about 4 hours
Charging Method: Type-C charging
Product Name: SOOCAS All-Care UVC Toothbrush Sanitizer
Model: D3
Rated Input: 5V⎓ 2.1A
Charging Time: about 3 hours
Charging Method: Type-C charging
Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

Даже если насадка для зубной щетки можно использовать в течение трех месяцев, она должна быть как новая каждый день

Очистка стены
Каждый подвешивание насадки на стене и держателя, что для ванной и кухни, после использования, чтобы сохранить чистоту и гигиену. Держатель присоединяется к ровной и гладкой стене, не подходит для шероховатых стен. Не ставьте в влажную, высокотемпературную среду, избегайте прямого солнечного света и не ставьте в вентиляционные трубы кондиционера.

Установите настенную вешалку
Снимите защитную пленку с задней стороны стеклянной и силиконовой защитной пленки на задней стороне держателя, прижмите к ровной поверхности настенную вешалку, прижмите силиконовую вешалку по направлению к ровной поверхности стены, и подождите 24 часа, чтобы обеспечить эффект клея. Не ставьте в влажную, высокотемпературную среду, не вставляйте и не прижимайте держатель для настенной вешалки в воздуховод, вентиляционное отверстие и другие места, которые могут повлиять на эффект присоски, и не устанавливайте настенную вешалку.

Установка и использование
1. Повесьте настенную вешалку на стену, повесьте крючок настенной вешалки для подвешивания на задней стороне стеклянной и нажмите на ручку, чтобы убедиться, что крючок для подвешивания надежно подвешен на крючке настенной вешалки, а ручка для подвешивания надежно прижата к стене. Поместите ручку для подвешивания в воздуховод, вентиляционное отверстие и другие места, которые могут повлиять на эффект присоски, и установите стеклянную вешалку.

Примечания
- При наклеивании настенной вешалку на обычную стену с отслаивающейся краской, порошком или неровной и плоской стеной. Стеклянная вешалка не подходит для использования.
- Не используйте повторно для наклеивания. Во избежание стены с повреждением, не используйте повторно.
- Не используйте стеклянную вешалку в влажной, высокотемпературной среде, избегайте прямого солнечного света и не ставьте в вентиляционные трубы кондиционера, вентиляционное отверстие и другие места, которые могут повлиять на эффект присоски.

Гуманизированный новый опыт использования электрической зубной щетки
Еще одна процедура обеспечивает более тщательный уход за полостью рта

Выньте и установите насадку зубной щетки
Насадка для зубной щетки уже установлена на заводе. Снимите упаковку, совместите насадку для зубной щетки с зарядной подставкой, вставьте прозрачную оболочку в зарядную подставку, слегка нажмите на насадку для зубной щетки. Если вы слышите звуки щелчка, это означает, что установка прошла успешно.

Теперь наслаждайтесь чистой полостью рта
Вам нужно только включить зубную щетку, и вы можете начать чистить зубы. Интеллектуальное распознавание привычек чистки зубной щетки и интеллектуальный выбор режима чистки позволяют эффективно ухаживать за зубами. Насадка для зубной щетки также обеспечивает легкий массаж, чтобы избежать чрезмерного раздражения и чистки.

Стерилизатор будет запускаться автоматически при каждом закрытии крышки
После чистки зубной щетки уберите насадку для зубной щетки в стерилизатор, закройте крышку, и стерилизатор автоматически стерилизует насадку для зубной щетки, чтобы щетинки оставались чистыми и гигиеничными. Стерилизатор также выполняет функцию зарядной подставки, чтобы зубная щетка всегда была готова к использованию.

Мы выступаем за уникальный дизайн для лучшего комфортного пользования, рекомендуем использовать электрическую зубную щетку SOOCAS All-Care Sonic D3 в течение нескольких лет.

Статус включения питания
В течение 10 секунд после запуска вы можете нажать кнопку включения/выключения, чтобы перейти в состояние паузы. В режиме паузы вы можете нажать и удерживать кнопку включения/выключения в течение 3 секунд, чтобы выключить.

Состояние паузы
Нажмите кнопку включения/выключения в течение 10 секунд после запуска, чтобы приостановить зубную щетку, нажмите и удерживайте кнопку включения/выключения в течение 30 секунд, чтобы выключить, после чего индикатор уровня заряда батареи будет мигать, зубная щетка автоматически выключится, если не нажимать кнопку паузы в течение 30 секунд.

Напоминание о зарядке
Когда вы обнаружите, что индикатор батареи зубной щетки мигает красным светом, это означает, что батарея слишком низкая. Следует как можно скорее зарядить зубную щетку.

Статус зарядки
Во время зарядки индикатор батареи будет медленно мигать.
Когда уровень заряда батареи ниже 80%, индикатор батареи будет медленно мигать зеленым светом.
Когда уровень заряда батареи достигает 80%, индикатор батареи будет постоянно гореть зеленым светом, указывая на то, что батарея полностью заряжена.

Функция зарядки режимов
Зубная щетка запомнит последний используемый режим, который вы выбрали в прошлый раз.

◇ Бережный режим
Для людей, которые впервые используют электрическую зубную щетку, или для людей, которые предпочитают другие или аналогичные режимы.

◇ Режим чистки
Предназначенный для эффективной чистки, подходит для людей, которые привыкли к режиму чистки других зубных щеток.

◇ Режим отбеливания
Разработан с тщательно рассчитанным отбеливанием предназначен для глубокого массажа чувствительных зубов, эффективно удаляет пятна, достигает эффекта отбеливания за 2 недели.

◇ Режим полирования
Благодаря переменным частотам и переменным направлениям для глубокого ухода, предназначен для удаления пятен от табака, чая и кофе, а также решения проблемы чувствительности.

SOOCAS

Режим чистки
Режим отбеливания
Режим полирования

Сертификаты
Данное изделие соответствует стандартам безопасности электромагнитного излучения. Если вы имеете медицинский имплантат, перед использованием изделия проконсультируйтесь с врачом или производителем медицинского имплантата.

Предупреждение
Не повреждайте аккумулятор во время использования инструмента, часто заменяйте или снимайте его. Предотвращайте разборку иглы, чтобы избежать повреждения изделия, возникновения угрозы безопасности и даже взрыва и пожара. Не используйте разобранный, проколотый или даже разобранный вами аккумулятор. Неправильная утилизация.
Не подвергайте аккумулятор высокой температуре. Если аккумулятор разряжен, если вы обнаружите, что аккумулятор не выключен, он будет выключен автоматически.

Предупреждение
Не повреждайте аккумулятор, часто заменяйте или снимайте его. Предотвращайте разборку иглы, чтобы избежать повреждения изделия, возникновения угрозы безопасности и даже взрыва и пожара. Не используйте разобранный, проколотый или даже разобранный вами аккумулятор. Неправильная утилизация.
Не подвергайте аккумулятор высокой температуре. Если аккумулятор разряжен, если вы обнаружите, что аккумулятор не выключен, он будет выключен автоматически.

Как средство защиты полости рта, гладкость зубной щетки сохраняется в течение 30 дней

При использовании утром и вечером, аккумулятор стерилизатора хватает на 30 дней
Стерилизатор может удовлетворить потребности вашей зубной щетки после каждого использования, чтобы вы могли пользоваться ею в течение 30 дней.

Индикаторы напоминания
Статус работы: Индикатор атмосферы стерилизатора будет горить в течение 5 минут, крышка будет открыта мигать в течение 5 секунд.
Аварийное питание: Если вода в состоянии стерилизации, индикатор атмосферы медленно мигает в течение 1 секунды, а затем полностью выключается. Стерилизатор автоматически выйдет из состояния стерилизации.
Разряд батареи: Индикатор атмосферы и индикатор уровня заряда батареи быстро погаснут.
Сигнал повреждения: Если стерилизация нижнего УФ-светодиодного стерилизатора ниже минимального напряжения, индикатор уровня заряда батареи медленно мигает красным светом в течение 3 секунд, после чего погаснет. Свяжитесь с нами в течение 10 секунд, после чего погаснет. Свяжитесь с нами в течение 10 секунд, чтобы получить гарантийное обслуживание.

Универсальный порт для быстрой зарядки
Стерилизатор поддерживает быструю зарядку, обеспечивает эффективную зарядку и удобное использование, использует порт Type-C, который является универсальным и совместим с стандартным стандартным зарядным портом, для быстрой, удобной зарядки требуется всего 5 часов.

Важная мера предосторожности!
Чтобы обеспечить хорошую производительность зарядки, убедитесь, что порты зарядки и стерилизации сухие перед использованием. Не используйте другие зарядные устройства или электронное оборудование для зарядки стерилизатора, так как это может привести к возгоранию. Ваша безопасность - наш главный приоритет!

Being used in the morning and evening, the sanitizer can last for 30 days.
The sanitizer will satisfy the toothbrush head after you brush your teeth. It can be used continuously for about 30 days after its battery capacity for your convenience.

Indicator Reminders
Working Status: The sanitizer's atmosphere indicator will turn on for 5 minutes, and the lid will be opened flashing for 5 seconds.
Power Emergency: when entering the sterilization status, the atmosphere indicator light will flash slowly for 1 seconds and then turn off. The sanitizer will automatically exit the sterilization status.
Out of Battery: The atmosphere indicator will battery level indicator flash quickly and then go out.
Damage Alarm: If the coil, sterilizing lamp is damaged and lower than the minimum voltage, the battery level indicator will flash red slowly, and the battery level indicator will flash for 3 seconds and then turn off. Please contact us in time for after-sales support.

Universal Port for Fast Charging
The sanitizer supports fast charging, ensuring efficient charging and convenient use. It uses the Type-C port, which is universal and compatible with the standard charging port. Convenient and fast charging can be completed in about 5 hours.

Important Safeguard
To ensure good charging performance, please ensure that the charging and sterilization ports are dry before use. Do not use other charging ports or other electronic equipment to charge the sanitizer, as it may cause fire. Your safety is our top priority!

Полоскание зубной щетки после использования
После чистки зубной щетки необходимо промыть щетину и шарнир под краном, чтобы гарантировать отсутствие остатков зубной пасты, затем вернуть на место. После каждого использования рекомендуется промывать ручку зубной щетки и голову зубной щетки каждые 3 дня.

Повесьте зубную щетку в стерилизатор после ополаскивания
После ополаскивания зубной щетки уберите ее влагу салфеткой и поместите лицевой стороной вверх в полотенце или мягкую ткань, а затем повесьте в стерилизатор. Увеличение подвешивания может предотвратить попадание воды на ручку для предотвращения намокания.

Портативная зубная щетка
Если вам нужно взять электрическую зубную щетку, снимите головку зубной щетки и поместите ее в сухой мешок, не оставляйте зубной щетки в влажной среде. Не ставьте электрическую зубную щетку для использования в домашнем хозяйстве. Рекомендуется не ставить в температурную среду, когда вы выходите из дома, чтобы предотвратить попадание воды в стерилизатор, что может привести к возгоранию.

Протирайте и очищайте стерилизатор
Стерилизатор предназначен для бытового использования. Рекомендуется протирать поверхность влажным полотенцем. Если стерилизатор используется для длительного обслуживания, протирайте только корпус, не используйте воду.

Прокладка цепочки в зубной щетке и стерилизаторе, рекомендуется использовать сухую ткань для протирания корпуса.

Стандартный базовый метод чистки зубов для электрических зубных щеток,Начальная цель чистки зубов может выходить за пределы вашего воображения

Прижмите щетинки к зубам под углом 45° к линии десен
Прижмите щетинки к линии десен под углом 45° и аккуратно массируйте десны.

Горизонтальная чистка зубов на короткой дистанции
Аккуратные движения зубной щеткой вперед и назад на короткое расстояние, обеспечивающие отсутствие давления щетины. Не используйте резкое нажатие и мягкое вытягивание; аккуратно толкайте зубную щетку вперед и тяните ее назад с легкой силой. Не используйте резкое нажатие и мягкое вытягивание.

Разделите рот на 4 части
Разделите свою ротовую полость на 4 части. Почистите каждую область зубов в течение 30 секунд, общее время составляет 120 секунд. Действие чистки будет приостановлено между каждым интервалом в 30 секунд, зубная щетка вибрирует, чтобы напомнить вас. Зубная щетка автоматически выключится спустя 2 минуты использования.

Полезные советы
Если вы считаете, что зубная паста распределяется зубной щеткой неравномерно, вы можете вручную распределить пасту по зубной щетке каждой секции перед использованием электрической зубной щетки.

Защита окружающей среды
Пользователи нашего продукта изделия, в соответствии с законами и нормами страны или региона, в которой они находятся, не имеют права выбрасывать несколько аккумуляторов в соответствующий обычным домашним мусором. Если вы не можете вынуть аккумулятор, пожалуйста, отправьте изделие в ближайшую точку утилизации или производителю. Профессиональные разборщики (назначенные компанией, которая несет ответственность за аккумулятор).

Предупреждение
1. Не повреждайте аккумулятор, чтобы избежать вырыва батареи или повреждения изделия, часто заменяйте.
2. Не допускайте короткого замыкания батареи, чтобы предотвратить возгорание.
3. Не используйте разобранный, проколотый или даже разобранный вами аккумулятор. Предотвращение разборки иглы приведет к повреждению изделия, но также приведет к серьезной угрозе безопасности, взрыву и даже пожару. Неправильная утилизация.
4. Не подвергайте аккумулятор высокой температуре. Если аккумулятор разряжен, если вы обнаружите, что аккумулятор не выключен, он будет выключен автоматически.

Способ извлечения батареи зубной щетки

Способ извлечения батареи стерилизатора

Разбирать батарею можно только при полном отсутствии заряда. Если вы обнаружите, что аккумулятор не выключен, пожалуйста, подождите, пока он выключится в результате разряда. Разрешено использовать только оригинальные аксессуары производителя. Неправильная утилизация аккумуляторов может привести к пожару.

Protéine Батарея может быть неверного загрузчика, не рекомендуется брать зарядкой в среде

Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

韩语

SOOCAS

사용자 설명서

SOOCAS 올케어 음파 전동 칫솔 D3

안전 주의 사항이 특히 중요합니다! 인내심을 가지고 읽어 보십시오.

경고
1. 이 제품은 신체적, 감각적, 정신적 장애가 있는 사람(어린이 포함) 또는 경험 및 지식이 없는 사람이 사용하도록 의도되지 않았으며 이러한 사람이 자신의 안전을 책임지는 성인의 지도 하에 사용하는 것은 예외입니다.
2. 습한 환경에서는 제품을 충전할 수 없습니다.
3. 습한 환경에서는 제품을 사용할 수 없습니다.
4. 치과 교정, 치아 수리, 치아 임플란트 등 사용자는 주의 깊게 사용하고 치과 의사에게 문의하십시오.
5. 이 제품은 전자기파 방출 표준을 준수합니다. 의료용 임플란트가 있는 경우 이 제품을 사용하기 전에 의료용 임플란트 제조업체 또는 의사에게 문의하십시오.
6. 이 제품은 치아 이외의 잇몸 및 혀용으로만 설계되었습니다. 다른 부위에 사용하지 마십시오. 불편함이 있으면 사용을 중단하고 치과 의사에게 문의하십시오.
7. 이 제품과 함께 제공된 충전기를 전용 충전 허브 또는 소비자 액세서리 또는 제조업체에서 구입한 것이 아닌 다른 용도로 사용하지 마십시오.
8. 충전하기 전에 충전기의 포트가 건조한지 확인하십시오.
9. 다른 전자 장치의 충전 포트를 사용하지 마십시오. 잘못된 충전 방법은 화재를 일으킬 수 있습니다.

주의
1. 제품을 처음 몇 일 동안 충전하면 입안이 아플 수 있고 잇몸이 출혈할 수 있습니다. 고주파 세척의 민감한 바늘에 대한 구강 및 혀 건강을 점진적으로 증가시킵니다. 출혈 또는 기타 불편함이 계속되면 제품 사용을 중단하고 치과 의사에게 문의하십시오.
2. 이 제품에는 내장 충전식 배터리가 있습니다. 불에 던지지 마십시오, 가열하지 마십시오, 자르고 충전하지 마십시오, 고온 환경에서 사용하거나 보관하지 마십시오.
3. 제품을 재활용하거나 현지 법률에 따라 폐기하십시오. 해당 국가 또는 지역.
4. 샤워 또는 샤워 중일 때는 칫솔을 사용하거나 청소하지 마십시오.

올케어 음파 전동 칫솔의 모든 구성 요소는 전문성과 감독 설계를 나타냅니다 (이전 버전

Product Name: SOOCAS All-Care Sonic Electric Toothbrush
Product Model: D3
Rated Input: 5V⎓ 1A
Charging Time: about 4 hours
Charging Method: Type-C charging
Product Name: SOOCAS All-Care UVC Toothbrush Sanitizer
Model: D3
Rated Input: 5V⎓ 2.1A
Charging Time: about 3 hours
Charging Method: Type-C charging
Manufacturer: Shenzhen Soocas Technology Co., Ltd.
Address: Room 401, 402, 1101, 1102, 1103, 1104, Building 2, Chengyuan Area, Nanshan District, Shenzhen, China
Tuyuan Subdistrict, Nanshan District, Shenzhen, China

칫솔 헤드 대신 세 개월 동안만 사용할 수 있더라도 칫솔은 매일 새로운 것처럼 유지되어야 합니다.

벽 세척
벽걸이 홀더를 깨끗하고 건조하게 유지하기 위해 사용하기 전에 벽걸이 홀더를 세척하십시오.

벽걸이 붙이기
벽걸이 홀더의 뒤쪽에서 실리콘 보호 필름을 벗겨내고 벽걸이 홀더를 고정하십시오.

설치 및 사용
1. 벽걸이 홀더를 벽에 걸고 벽걸이 홀더의 걸이 구멍을 벽걸이 홀더의 후크에 걸고 벽걸이 홀더를 왼쪽 또는 오른쪽으로 천천히 당겨 벽걸이 홀더가 후크에 단단히 걸려 있는지 확인하십시오. 칫솔 헤드를 놓고 벽걸이 홀더를 붙이고 AC 덕트 깊숙이 눌러 벽걸이 홀더를 설치하십시오.

참고
- 벽걸이 홀더를 벽에 붙이지 마십시오. 페인트가 벗겨지거나 가루가 있거나 평탄하지 않은 일반 벽에 붙이지 마십시오.
- 벽걸이 홀더를 2차 붙이기 위해 제거하지 마십시오. 벽에 손상을 방지하기 위해 재사용하지 마십시오.
- 벽걸이 홀더를 습한 고온 환경에 두지 마십시오. 직사광선을 피하고 AC 덕트, 환기 덕트 또는 흡입컵 효과에 영향을 미칠 수 있는 기타 장소에 벽걸이 홀더를 설치하지 마십시오.

칫솔 헤드 교체 및 장착
칫솔 헤드 베이스는 공장에서 설치되었습니다. 보호 포장을 벗기고 칫솔 헤드를 충전 허브에 맞추고 투명 쉘을 충전 베이스에 삽입하고 칫솔 헤드를 부드럽게 누릅니다. "딸깍" 소리가 들리면 설치가 성공했다는 것을 의미합니다.

즐거운 양치질
사실 제품을 켜고 칫솔질을 하기만 하면 됩니다. 장치는 자동으로 인식하고 스마트 모드 선택 기능을 사용하여 가장 적합한 세척 모드를 선택하여 효율적인 세척을 달성합니다. 칫솔 헤드는 잇몸을 자극하지 않고 부드럽게 마사지합니다.

깨