Kyvol

COUNTERTOP
DISHWASHER
SW-C7200W

User Manual

Please carefully read the User Manual before using the product, and keep it safe for future reference.

V1.0

ENGLISH : 01-22 .

русский : 23-46 .

ENGLISH

Thank you for choosing our product.
If you have any questions, concerns, or ideas on this key, please contact us at:
support@kyvol.com

IMPORTANT SAFETY INSTRUCTIONS

WARNING:

Read carefully. Failure to follow these instructions can result in injury or property damage.

- Only qualified and authorized personnel may install, repair, maintain, or modify the dishwasher.
- Unauthorized modifications to the dishwasher may cause malfunctions, injuries, or damage to the dishwasher and void the warranty.
- Do not use the dishwasher if it shows any signs of damage or malfunction. Immediately disconnect the power and contact a qualified technician for inspection and repair.
- Do not use extension cords or adapters to connect the dishwasher to the power supply. Use only a dedicated, properly rated outlet to ensure safe operation.
- Do not place or store flammable, explosive, or corrosive substances near the dishwasher.
- Do not place heavy objects on the dishwasher or allow children to climb on it.
- Do not use the dishwasher for purposes other than washing dishes.
- Do not touch the electrical components while the dishwasher is in operation.
- Ensure the dishwasher is disconnected from the power supply before any cleaning or maintenance.
- Do not allow children or pets to play with the dishwasher. Keep it out of their reach.
- Do not use the dishwasher in a wet environment or expose it to direct water sprays.
- Do not place the dishwasher near heat sources, such as stoves or heaters, to avoid overheating and fire risks.
- Do not use the dishwasher if the power cord is damaged. Immediately stop using it and contact a qualified technician for repair or replacement.
- Do not place the dishwasher in a location where it may be exposed to extreme temperatures or direct sunlight.
- Do not use the dishwasher in an environment with high humidity or dust.
- Do not place the dishwasher on an unstable surface to prevent tipping or falling.
- Do not place the dishwasher on a surface that is not level or stable.
- Do not place the dishwasher on a surface that is not level or stable.

GROUNDING INSTRUCTIONS

- Ensure the dishwasher is properly grounded to prevent electrical hazards. Incorrect grounding may cause electrical shock or damage to the dishwasher and other electrical devices. Only qualified technicians should perform grounding installation and ensure it complies with local electrical regulations.
- WARNING: Improper grounding can increase the risk of electric shock.
- Do not connect the grounding wire to gas pipes, water pipes, or other unsuitable objects. Ensure the grounding wire is connected to a dedicated grounding point to avoid interfering with other electrical devices.

SAVE THESE INSTRUCTIONS

SAFETY WARNINGS

- Keep the dishwasher away from the reach of children.
- Do not place the dishwasher near heat sources, such as stoves or heaters.

- Keep the dishwasher away from heat sources, such as stoves or heaters.
- Do not place the dishwasher near flammable or explosive substances.
- Do not place heavy objects on the dishwasher or allow children to climb on it.
- Do not use the dishwasher for purposes other than washing dishes.
- Do not use extension cords or adapters to connect the dishwasher to the power supply.
- Do not place or store flammable, explosive, or corrosive substances near the dishwasher.
- Do not place heavy objects on the dishwasher or allow children to climb on it.
- Do not use the dishwasher for purposes other than washing dishes.
- Do not touch the electrical components while the dishwasher is in operation.
- Ensure the dishwasher is disconnected from the power supply before any cleaning or maintenance.
- Do not allow children or pets to play with the dishwasher. Keep it out of their reach.
- Do not use the dishwasher in a wet environment or expose it to direct water sprays.
- Do not place the dishwasher near heat sources, such as stoves or heaters, to avoid overheating and fire risks.
- Do not use the dishwasher if the power cord is damaged. Immediately stop using it and contact a qualified technician for repair or replacement.
- Do not place the dishwasher in a location where it may be exposed to extreme temperatures or direct sunlight.
- Do not use the dishwasher in an environment with high humidity or dust.
- Do not place the dishwasher on an unstable surface to prevent tipping or falling.
- Do not place the dishwasher on a surface that is not level or stable.
- Do not place the dishwasher on a surface that is not level or stable.

GROUNDING INSTRUCTIONS

- Ensure the dishwasher is properly grounded to prevent electrical hazards. Incorrect grounding may cause electrical shock or damage to the dishwasher and other electrical devices. Only qualified technicians should perform grounding installation and ensure it complies with local electrical regulations.
- WARNING: Improper grounding can increase the risk of electric shock.
- Do not connect the grounding wire to gas pipes, water pipes, or other unsuitable objects. Ensure the grounding wire is connected to a dedicated grounding point to avoid interfering with other electrical devices.

WHAT'S INCLUDED

KNOW YOUR DISHWASHER

Dishwasher

LCD Display

Control Panel

LCD Display

Control Panel

LCD Display

- 1/2 Load
- Delay Start Remaining Time/Water Hardness
- Program Indicator/Water Hardness Indicator
- Rinse Aid Indicator/Salt Indicator
- Water Hardness Indicator
- Program Indicator
- Cycle Indicator
- Remaining Time
- Start/Pause Indicator
- Cancel Indicator
- Power Indicator

HOSE INSTALLATION

WARNING!

- Do not use the pressure hose to connect the dishwasher.
- Do not use the old hose.
- Do not use the water inlet hose to connect the dishwasher.
- Do not use the water inlet hose to connect the dishwasher. Use the pressure hose provided with the dishwasher.
- Do not use the water inlet hose to connect the dishwasher. Use the pressure hose provided with the dishwasher.

1. Drain Hose Installation

Step 1:
Install the drain hose (Item 1) from the **Drain Hose Fixer** to the **Drain Outlet Connector**. Then, secure it using the **Hose Clamp**.

---

1. Water Inlet Hose Installation (Optional)

Step 1:
Install the water inlet hose (Item 2) to the **Water Inlet Hole** on the dishwasher and connect it to the **Water Inlet Valve**.

Note:
- Ensure the hose connection is secure and free of leaks.
- Do not bend or kink the hose to prevent water flow issues.

Step 2:
Connect the other end of the water inlet hose to the **Water Inlet Valve**.

Note:
- If the water inlet hose provided does not fit your faucet, please prepare a suitable adapter, ensure it is tight and secure to prevent leaks, and avoid using excessive force.

OPERATING VIA KYVOL APP

App Downloading and Installation

1. Open App Store or Google Play Store and search for "Kyvol" to download and install the app.

Note:
- If you can't find the app in your region, try using a VPN to download it.

2. Open the app, tap **Sign Up/Sign In**, and select your preferred method to create an account or log in.

Note:
- If you forget your password, tap on "Forgot Password" to reset it.

APP INSTALLATION AND LOGIN

Scan the QR code below to download and install the app. If you have the app, log in directly.

Note:
- Ensure your mobile device is connected to the internet.

Connect your mobile device to the app and pair

Note:
- Ensure your mobile device is connected to a 2.4GHz Wi-Fi network.

USE YOUR DISHWASHER

1. Load the Dishwasher Baskets

Step 1:
Pull out the lower rack and load dishes according to the recommended layout.

Note:
- Ensure dishes are not too close to the heating element to avoid interfering with the drying function.
- Do not place large, heavy dishes in the upper rack to avoid damage to the rack and ensure even water distribution.

---

2. Add Detergent

Step 1:
Open the dishwasher door and slide the **Dishwasher Detergent Dispenser** cover to the left to **Open/Target Position**.

---

1. Power On

Step 1:
Ensure the dishwasher is connected to a grounded power outlet. Press the **Power** button to turn on the dishwasher.

2. Add Water

Step 1:
Open the **Water Inlet Valve** manually.

Note:
- Ensure the water inlet hose is connected to the water inlet valve and that the hose is not kinked or blocked.

Step 2:
Select a **Anti-Water Recycle**.

- Anti-water recycle: Water will be recycled and reused for the next cycle, saving water.
- Non-anti-water recycle: Water will be drained after each cycle.

Note:
- Ensure the water inlet valve is working properly.
- If hose is kinked, ensure the water flow.
- If water is not flowing, check the water supply.

To select the recommended **Program**, press **Program** button.

3. Select Program and Start Washing

Step 1:
Select the appropriate washing program based on the dishes and their level of dirtiness.

Program	Type	Washing Temperature	Applicable Dishes	Recommended Detergent
Intensive	Pre-rinse(optional) Main wash Rinse Drying	High-temperature	Heavily soiled dishes	Tablets
Normal	Pre-rinse(optional) Main wash Rinse Drying	Medium-temperature	Regular dishes	Tablets
Quick	Main wash Rinse Drying	Medium-temperature	Lightly soiled dishes	Tablets
Soak	Soaking Rinse	Low-temperature	Soaked dishes	Powder
Rinse	Rinse Drying	Low-temperature	Rinse dishes	Tablets
Glass	Pre-rinse(optional) Main wash Rinse Drying	Medium-temperature	Glass	Tablets

---

Step 2:
Press the **Start/Pause** button to start the cycle.

Note:
- To cancel a program, press and hold the **Cancel** button for 3 seconds.

FILTER ASSEMBLY

Step 1:
Remove the **Filter Assembly** from the **Lower Spray Arm**.

Step 2:
Disassemble the **Filter Assembly** in the following sequence: coarse filter, fine filter, and flat filter.

Step 3:
Clean the components with a soft brush or cloth to remove any dirt and debris.

Step 4:
Reassemble the components in the reverse order and ensure they are securely fastened.

SPRAY ARMS

Step 1:
Remove the **Lower Spray Arm**.

Step 2:
Clean the spray holes with a toothpick.

Step 3:
Reinstall the **Lower Spray Arm** and ensure it is tightly fastened.

STORAGE

- Ensure the dishwasher is stored in a dry, well-ventilated environment to prevent moisture and mold.
- Avoid exposure to direct sunlight and high temperatures to prevent damage to the dishwasher.
- Do not place heavy objects on the dishwasher to prevent deformation or damage.

TRANSPORTATION

SPECIFICATIONS

Product Dimensions	17.7×17.7×17.7 in
Product Weight	17.6 lbs
Rated Voltage	120V
Rated Frequency	60Hz
Rated Power	1200W
Water Inlet Pressure	0.1-0.8MPa
Water Inlet Temperature	0-70℃
Water Capacity	1.5-2.5L
Noise Level	≤55dB(A)
Certifications	CE, UKCA, FCC, ROHS, UL, CSA, ETL, ENERGY

MAINTENANCE AND CARE

- Clean the exterior of the dishwasher with a soft cloth and mild detergent.
- Check the spray arms for blockages and remove any debris to ensure even water distribution.
- Regularly clean the filter to prevent clogs and maintain water flow.
- Check the hoses for any signs of wear or damage and replace them if necessary.

TROUBLESHOOTING GUIDE

1. Error Code Explanations

Error Code	Possible Cause	Solution
E1	Water Inlet Fault	1. Check the water inlet hose for kinks or blockages. 2. Ensure the water inlet valve is functioning properly. 3. If the issue persists, contact a qualified technician for inspection and repair.
E2	Drainage Fault	1. Check the drain hose for kinks or blockages. 2. Ensure the drain pump is functioning properly. 3. If the issue persists, contact a qualified technician for inspection and repair.
E3	Temperature Sensor Fault	1. Restart the dishwasher and check if the error code appears again. 2. If the error code appears again, contact a qualified technician for inspection and repair.
E4	Overflow Fault	1. Check the water level sensor for blockages or damage. 2. Ensure the water inlet valve is functioning properly. 3. If the issue persists, contact a qualified technician for inspection and repair.
E5	Overheating Protection	1. Allow the dishwasher to cool down before restarting. 2. If the issue persists, contact a qualified technician for inspection and repair.
E6	Water Leakage	1. Check the water inlet hose and drain hose for leaks. 2. Ensure the dishwasher is properly sealed. 3. If the issue persists, contact a qualified technician for inspection and repair.

2. Frequently Asked Questions

Q1: The dishwasher is not turning on. What should I do?
A: The dishwasher is not turning on? Please check the following steps to troubleshoot the issue:
- Ensure the power cord is properly connected to the power outlet.
- Check the circuit breaker or fuse box to ensure the power supply is not interrupted.
- Verify that the door is fully closed, as the dishwasher will not start if the door is not properly closed.
- If the issue persists, contact a qualified technician for inspection and repair.

Q2: The dishwasher is not draining properly. What should I do?
A: If the dishwasher is not draining properly, please check the following:
- Check the drain hose for kinks or blockages and ensure it is properly connected.
- Ensure the drain pump is functioning properly.
- If the issue persists, contact a qualified technician for inspection and repair.

Q3: The dishwasher is not cleaning dishes properly. What should I do?
A: If the dishwasher is not cleaning dishes properly, please check the following:
- Ensure the spray arms are not blocked and can rotate freely.
- Check the water level and ensure it is sufficient.
- Use the appropriate detergent and ensure it is not expired.
- If the issue persists, contact a qualified technician for inspection and repair.

Q4: The door cannot be opened. What should I do?
A: If the door cannot be opened, please check the following:
- Ensure the door latch is not stuck and can be released.
- If the door is still locked, wait for the cycle to complete or cancel the cycle before opening the door.
- If the issue persists, contact a qualified technician for inspection and repair.

Q5: How to reset the dishwasher?
A: To reset the dishwasher, press and hold the **Cancel** button for 3 seconds. The dishwasher will reset and return to the standby mode.

Q6: The water in the dishwasher is not drained. What should I do?
A: If the water in the dishwasher is not drained, please check the following:
- Check the drain hose for kinks or blockages and ensure it is properly connected.
- Ensure the drain pump is functioning properly.
- If the issue persists, contact a qualified technician for inspection and repair.

Q7: How to contact the manufacturer?
A: If you need to contact the manufacturer, please contact us at: support@kyvol.com

---

русский

Благодарим за покупку нашей продукции.
Если у вас есть вопросы, замечания или идеи, свяжитесь с нами по адресу:
support@kyvol.com

ВАЖНЫЕ ИНСТРУКЦИИ ПО БЕЗОПАСНОСТИ

ПРЕДУПРЕЖДЕНИЕ:

Внимательно прочтите. Невыполнение этих инструкций может привести к травме или повреждению имущества.

- Только квалифицированный и уполномоченный персонал может устанавливать, ремонтировать, обслуживать или модифицировать посудомоечную машину.
- Несанкционированные модификации посудомоечной машины могут привести к неисправностям, травмам или повреждению посудомоечной машины и аннулировать гарантию.
- Не используйте посудомоечную машину, если она показывает признаки повреждения или неисправности. Немедленно отключите питание и обратитесь к специалисту для проверки и ремонта.
- Не используйте удлинители или адаптеры для подключения посудомоечной машины к источнику питания. Используйте только выделенную, должным образом рассчитанную розетку для обеспечения безопасной работы.
- Не размещайте и не храните рядом с посудомоечной машиной горючие, взрывоопасные или коррозионные вещества.
- Не размещайте тяжелые предметы на посудомоечной машине и не позволяйте детям залезать на нее.
- Не используйте посудомоечную машину в целях, отличных от мытья посуды.
- Не прикасайтесь к электрическим компонентам, пока посудомоечная машина работает.
- Убедитесь, что посудомоечная машина отключена от источника питания, прежде чем приступать к любым работам по очистке или обслуживанию.
- Не допускайте детей или домашних животных играть с посудомоечной машиной. Держите ее подальше от их досягаемости.
- Не используйте посудомоечную машину в сырой среде и не допускайте попадания на нее прямых струй воды.
- Не размещайте посудомоечную машину рядом с источниками тепла, такими как плиты или обогреватели, во избежание перегрева и пожарной опасности.
- Не используйте посудомоечную машину, если шнур питания повреждён. Немедленно прекратите использование и обратитесь к специалисту для замены или ремонта.
- Не размещайте посудомоечную машину в местах, где она может подвергаться воздействию экстремальных температур или прямых солнечных лучей.
- Не используйте посудомоечную машину в среде с высокой влажностью или запылённостью.
- Не размещайте посудомоечную машину на неустойчивой поверхности, чтобы предотвратить опрокидывание или падение.
- Не размещайте посудомоечную машину на поверхности, которая не является ровной или устойчивой.
- Не размещайте посудомоечную машину на поверхности, которая не является ровной или устойчивой.

ТРЕБОВАНИЯ ТЕХНИКИ БЕЗОПАСНОСТИ

- Не размещайте посудомоечную машину рядом с источниками тепла, такими как плиты или обогреватели.
- Не размещайте посудомоечную машину рядом с горючими или взрывоопасными веществами.
- Не размещайте тяжелые предметы на посудомоечной машине.
- Не используйте посудомоечную машину для чистки посуды.
- Не используйте удлинители.
- Не используйте посудомоечную машину, если шнур питания повреждён.
- Не размещайте посудомоечную машину в сырой среде.
- Не размещайте посудомоечную машину рядом с источниками тепла.
- Не размещайте посудомоечную машину рядом с горючими или взрывоопасными веществами.
- Не размещайте тяжелые предметы на посудомоечной машине.
- Не используйте посудомоечную машину для чистки посуды.
- Не используйте удлинители.
- Не используйте посудомоечную машину, если шнур питания повреждён.
- Не размещайте посудомоечную машину в сырой среде.
- Не размещайте посудомоечную машину рядом с источниками тепла.
- Не размещайте посудомоечную машину рядом с горючими или взрывоопасными веществами.
- Не размещайте посудомоечную машину в местах, где она может подвергаться воздействию экстремальных температур или прямых солнечных лучей.
- Не используйте посудомоечную машину в среде с высокой влажностью или запылённостью.
- Не размещайте посудомоечную машину на неустойчивой поверхности, чтобы предотвратить опрокидывание или падение.
- Не размещайте посудомоечную машину на поверхности, которая не является ровной или устойчивой.
- Не размещайте посудомоечную машину на поверхности, которая не является ровной или устойчивой.

ИНСТРУКЦИИ ПО ЭКОЛОГИИ

- Для экономии воды и энергии выбирайте программы с низкой температурой и короткие циклы, когда посуда не слишком грязная.
- Перед загрузкой ополаскивайте посуду, чтобы сократить время предварительной стирки и снизить потребление воды.
- Регулярно проверяйте и очищайте фильтр и форсунки, чтобы обеспечить эффективность работы и предотвратить утечки.
- Утилизация: Соблюдайте местные законы и правила по утилизации бытовой техники. Обратитесь к специалисту по утилизации или в местный центр переработки, чтобы узнать о правильном способе утилизации.
- Переработка: Разберите посудомоечную машину на части и сортируйте компоненты по материалам (пластик, металл, электронные детали) для переработки.
- Опасные вещества: Обратите внимание на наличие в посудомоечной машине опасных веществ, таких как батареи или электронные компоненты, и обеспечьте их безопасную утилизацию.
- Экологичность: Рассмотрите возможность замены посудомоечной машины на более экологичную модель, если ваша текущая машина потребляет слишком много воды или энергии.

КОМПЛЕКТ ПОСТАВКИ

ЗНАКОМСТВО С ПОСУДОМОЙКОЙ МАШИНОЙ

Посудомоечная машина

ЖК-дисплей

Панель управления

ЖК-дисплей

- 1/2 Load
- Delay Start Remaining Time/Water Hardness
- Program Indicator/Water Hardness Indicator
- Rinse Aid Indicator/Salt Indicator
- Water Hardness Indicator
- Program Indicator
- Cycle Indicator
- Remaining Time
- Start/Pause Indicator
- Cancel Indicator
- Power Indicator

УСТАНОВКА ШЛАНГА

ПРЕДУПРЕЖДЕНИЕ!

- Не используйте шланг высокого давления для подключения посудомоечной машины.
- Не используйте старый шланг.
- Не используйте подключение шланга высокого давления для подключения посудомоечной машины. Используйте шланг высокого давления, прилагаемый к посудомоечной машине.
- Не используйте подключение шланга высокого давления для подключения посудомоечной машины. Используйте шланг высокого давления, прилагаемый к посудомоечной машине.

1. Установка сливного шланга

Шаг 1:
Установите сливной шланг (Деталь 1) от **Фиксатора сливного шланга** к **Сливному патрубку**. Затем закрепите шланг **Хомутом**.

---

1. Установка подводящего шланга (дополнительно)

Шаг 1:
Установите подводящий шланг (Деталь 2) к **Впускному отверстию** на посудомоечной машине и к **Впускному клапану**.

Шаг 2:
Подсоедините другой конец подводящего шланга к **Впускному клапану**.

Примечание:
- Убедитесь, что соединение надежно и герметично, чтобы избежать утечек.
- Если предоставленный шланг высокого давления не подходит к вашему крану, подготовьте подходящий адаптер, обеспечьте плотное и надежное соединение, чтобы избежать утечек, и избегайте чрезмерного усилия.

Примечание:
- Если вы используете подводящий шланг высокого давления, убедитесь, что соединение надежно и герметично, чтобы избежать утечек.
- Если предоставленный подводящий шланг высокого давления не подходит к вашему крану, подготовьте подходящий адаптер, обеспечьте плотное и надежное соединение, чтобы избежать утечек, и избегайте чрезмерного усилия.

Шаг 1:
Подсоедините другой конец подводящего шланга высокого давления к **Впускному клапану**.

ЭКСПЛУАТАЦИЯ ПОСУДОМОЕЧНОЙ МАШИНЫ

2. Загрузка корзин посудомоечной машины

Шаг 1:
Выдвиньте нижнюю корзину.

Шаг 2:
Загрузите посуду согласно рекомендуемой схеме.

Примечание:
- Убедитесь, что посуда не слишком близко к нагревательному элементу, чтобы не мешать функции сушки.
- Не ставьте большие, тяжелые предметы в верхнюю корзину, чтобы не повредить корзину и обеспечить равномерное распределение воды.

1. Добавление моющего средства

Шаг 1:
Откройте дверцу посудомоечной машины и сдвиньте крышку **Дозатора моющего средства** влево до **Открыть/Целевое положение**.

Примечание:
- Если вы используете моющие таблетки, убедитесь, что таблетка полностью растворилась, чтобы предотвратить остатки моющего средства на посуде.

Шаг 1:
Выберите **Моющее средство** в зависимости от посуды и степени загрязненности.

---

2. Выбор программы и начало мытья

Шаг 1:
Нажмите кнопку **Выбор программы**, чтобы выбрать **Программу**.

Программа	Тип	Температура мытья	Подходящие блюда	Рекомендуемое моющее средство
Интенсивная	Предварительное ополаскивание(опционально) Основная мойка Ополаскивание Сушка	Высокотемпературная	Сильно загрязненные блюда	Таблетки
Обычная	Предварительное ополаскивание(опционально) Основная мойка Ополаскивание Сушка	Среднетемпературная	Обычная посуда	Таблетки
Быстрая	Основная мойка Ополаскивание Сушка	Среднетемпературная	Слабо загрязненные блюда	Таблетки
Замачивание	Замачивание Ополаскивание	Низкотемпературная	Замоченные блюда	Порошок
Ополаскивание	Ополаскивание Сушка	Низкотемпературная	Ополаскивание посуды	Таблетки
Стекло	Предварительное ополаскивание(опционально) Основная мойка Ополаскивание Сушка	Среднетемпературная	Стекло	Таблетки

Шаг 2:
Нажмите кнопку **Пуск/Пауза**, чтобы запустить цикл.

Примечание:
- Чтобы отменить программу, нажмите и удерживайте кнопку **Отмена** в течение 3 секунд.

ФИЛЬТР В СБОРЕ

Шаг 1:
Выньте **Фильтр в сборе** из **Нижнего распылителя**.

Шаг 2:
Разберите **Фильтр в сборе** в следующем порядке: крупный фильтр, тонкий фильтр, плоский фильтр.

Шаг 3:
Очистите компоненты мягкой щеткой или тряпкой, чтобы удалить грязь и мусор.

Шаг 4:
Соберите компоненты в обратном порядке, убедитесь, что они надежно закреплены.

РАЗБРЫЗГИВАТЕЛИ

Шаг 1:
Снимите **Нижний распылитель**.

Шаг 2:
Очистите отверстия распылителя мягкой щеткой или зубочисткой, чтобы удалить остатки. Убедитесь, что отверстия свободны, чтобы обеспечить равномерное распределение воды.

Шаг 3:
Переустановите **Нижний распылитель** и убедитесь, что он надежно закреплен.

ОБСЛУЖИВАНИЕ И УХОД

- Регулярно очищайте внешнюю поверхность посудомоечной машины мягкой тряпкой и моющим средством.
- Проверяйте форсунки на предмет блокировки и удаляйте любые остатки, чтобы обеспечить равномерное распределение воды.
- Регулярно очищайте фильтр, чтобы предотвратить засоры и обеспечить бесперебойную подачу воды.
- Проверяйте шланги на предмет износа и повреждений и при необходимости заменяйте их.

ХРАНЕНИЕ

- Убедитесь, что посудомоечная машина хранится в сухом, хорошо вентилируемом месте, чтобы предотвратить скопление влаги и плесени.
- Избегайте прямого воздействия солнечных лучей и высоких температур, чтобы предотвратить повреждение посудомоечной машины.
- Не размещайте тяжелые предметы на посудомоечной машине, чтобы предотвратить деформацию или повреждение.

ТРАНСПОРТИРОВКА

ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

Размеры посудомоечной машины	17.7×17.7×17.7 in
Вес посудомоечной машины	17.6 lbs
Номинальное напряжение	120V
Номинальная частота	60Hz
Номинальная мощность	1200W
Давление на входе	0.1-0.8MPa
Температура на входе	0-70℃
Объем	1.5-2.5L
Уровень шума	≤55dB(A)
Сертификаты	CE, UKCA, FCC, ROHS, UL, CSA, ETL, ENERGY

УСТРАНЕНИЕ НЕИСПРАВНОСТЕЙ

1. Коды ошибок и их расшифровки

Код ошибки	Возможная причина	Решение
E1	Неисправность подачи воды	1. Проверьте шланг подачи воды на наличие перегибов или блокировок. 2. Убедитесь в исправной работе клапана подачи воды. 3. Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.
E2	Неисправность дренажа	1. Проверьте дренажный шланг на наличие перегибов или блокировок. 2. Убедитесь в исправной работе дренажного насоса. 3. Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.
E3	Неисправность датчика температуры	1. Перезапустите посудомоечную машину и проверьте, появляется ли код ошибки снова. 2. Если код ошибки появляется снова, обратитесь к специалисту для проверки и ремонта.
E4	Переполнение	1. Проверьте датчик уровня воды на наличие блокировок или повреждений. 2. Убедитесь в исправной работе клапана подачи воды. 3. Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.
E5	Перегрев	1. Дайте посудомоечной машине остыть перед повторным запуском. 2. Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.
E6	Утечка воды	1. Проверьте шланг подачи воды и дренажный шланг на наличие утечек. 2. Убедитесь в герметичности посудомоечной машины. 3. Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.

Если вы не можете устранить неисправность, свяжитесь с нашей технической поддержкой по адресу support@kyvol.com.

---

2. Часто задаваемые вопросы

Q1: Посудомоечная машина не включается. Что делать?
A: Если посудомоечная машина не включается, проверьте следующие пункты:
- Убедитесь, что шнур питания подключен к розетке.
- Проверьте автоматический выключатель или предохранитель, чтобы убедиться в отсутствии перебоев в подаче питания.
- Убедитесь, что дверца плотно закрыта, поскольку машина не запустится, если дверца не закрыта должным образом.
- Если проблема сохраняется, обратитесь к специалисту для проверки и ремонта.

Q2: Посудомоечная машина не сливает во