Infinix

INSTRUCTIONS

Model: ZL513

English
Preparing your Computer
Product Overview
Left Side
Right Side
Bottom Side
Understanding the Keyboard
Using the Touchpad/Clickpad
Windows 11 touchpad usage
Do's
Don'ts

Bahasa Indonesia
Menyiapkan Komputer Anda
Ikhtisar Produk
Sisi Kiri
Sisi Kanan
Sisi Bawah
Memahami Keyboard
Menggunakan Touchpad/Clickpad
Penggunaan Touchpad Windows 11
Boleh Dilakukan
Tidak Boleh Dilakukan

ไทย
เริ่มใช้งานคอมพิวเตอร์ของคุณ
ภาพรวมผลิตภัณฑ์
ด้านซ้าย
ด้านขวา
ด้านล่าง
การทำความเข้าใจแป้นพิมพ์
การใช้ทัชแพด/คลิกแพด
การใช้งานทัชแพดของ Windows 11
ข้อควรทำ
ข้อห้าม

Français
Préparation de votre ordinateur
Présentation du produit
Côté gauche
Côté droit
Dessous
Présentation du clavier
Utilisation du pavé tactile
Utilisation du pavé tactile sous Windows 11
Utilisation incorrecte
Utilisation correcte

Русский
Подготовка компьютера
Обзор устройства
Левая сторона
Правая сторона
Нижняя сторона
Использование клавиатуры
Использование тачпада/кликпада
Использование touchpad в Windows 11
Не следует делать
Следует делать

العربية
إعداد جهاز الكمبيوتر الخاص بك
نظرة عامة على المنتج
الجانب الأيسر
الجانب الأيمن
الجانب السفلي
لوحة المفاتيح
استخدام لوحة التتبع/لوحة النقر
استخدام لوحة التتبع في Windows 11
الفعل
لا تفعل

Preparing your Computer

Connect the charging output plug of the AC adapter to the Type-C Jack or DC in Jack on the side of the computer.

The display panel can be opened to a wide range of angles for optimal viewing.

Attaching or forcing the AC adapter beyond 135 degrees will cause damage to the hinges and the adapter.

Product Overview

A. Digital Microphones
Internal microphones.

B. Camera
Used for video services.

C. LCD Screen
Displays all computer output.

D. Power Button/Fingerprint Reader
Press to turn on the computer when the power is off. Press briefly when the computer is on to put the computer into sleep mode. Press and hold for 10 seconds to force shutdown. Place your finger on the sensor to authenticate your fingerprint.

E. Speakers
Stereo audio output.

F. Keyboard
Provides input to the computer through the Control Center utility.

G. Touchpad/Clickpad
Touch-sensitive pointing device which functions like a mouse.

Left Side

A. Type-C
Supports USB devices via these ports, such as a USB flash drive, keyboard, or mouse.

B. Power Connector
Connect the AC adapter to this connector.

C. HDMI Port
Supports high-definition digital video connections.

D. USB 3.2
Supports USB devices via this port, such as a USB flash drive, keyboard, or mouse.

E. Type-C
Supports USB devices via this port, such as a USB flash drive, keyboard, or mouse.

Right Side

F. Performance switch
Switch between Silent, Balance mode, Sit-Stand, Overboost mode (Fn+M).

G. USB 3.2
Supports USB devices via these ports, such as a USB flash drive, keyboard, or mouse.

H. Headphone Jack
Connect amplified speakers or headphones into this jack.

I. Card Reader
Supports the Micro SD memory cards.

Bottom Side

A. Speakers
Stereo audio output.

B. Vents
The thermal vents are designed to cool the internal components and prevent overheating.

Understanding the Keyboard

The following defines the use of function keys and other special keys located on specialty hotkeys/shortcuts, which can be accessed by pressing the Fn key in conjunction with the function keys (F1-F12) or alphanumeric keys.

Using the Touchpad/Clickpad

The touchpad/clickpad is a pointing device which senses movement on its surface. This means that the cursor/pointer responds to your touch. Place your finger on the touchpad/clickpad and move it around to place the cursor/pointer. Tap or click the left button (below the touchpad/clickpad) to pick up/drop (select/deselect) items.

Tap the touchpad/clickpad twice quickly (double-click) to open a program or perform other tasks. Tap and hold the second tap for a few seconds to drag items across the screen.

Windows 11 touchpad usage

Gesture	Action
Single-finger slide	Move cursor/pointer
Single-finger tap (tap, double-tap, tap-and-hold)	Mouse left button click (select, double-click, drag)
Two-finger tap	Mouse right button click
Two-finger slide	Scroll up/down or pan/zoom (scroll, pan, zoom)
Two-finger pinch	Zoom in / zoom out

Do's

1. Disconnect all the peripherals which are connected when the laptop is not in use.
2. Keep the laptop away from the heat sources, direct sunlight, and keep it away from sharp edges and serious flame immediately after use, otherwise these devices will other electronic devices.
3. Wipe non-sticky the Laptop, please using the Antistatic cloth.
4. Use the Laptop in a well-ventilated place.
5. Delete unwanted files from and there otherwise it may occupy more space.
6. Keep the Laptop in a cool place, otherwise it may cause the Laptop to overheat.
7. Always lift or move the Laptop with both the hands. Handle gently.
8. Place the Laptop in plain and smooth surface while using.
9. Use the Laptop on a flat surface.
10. Keep the Laptop away from water, moisture, and dust.
11. Clean the Laptop with a soft cloth, otherwise it may scratch the screen.
12. In case of any accident with the Laptop, register your complaint and approach the nearest service center.

Don'ts

1. Do not place the Laptop near magnetic or electromagnetic device such as Permanent Magnet, TV set, and Mobile phone, charger.
2. Do not place the Laptop near the heat source, direct sunlight or in a small and not ventilated place.
3. Do not place the Laptop on a sharp / pointed objects or any Liquid.
4. Never keep the Laptop in TWO condition in the bed while sleeping. Always keeps it in a flat surface or in a table. Otherwise it may cause the Laptop to overheat.
5. Do not place the Laptop upside down, otherwise it may cause the Laptop to overheat.
6. Do not place the Laptop on the Bed, Sofa, Blanket, Pillow, Cushion, Carpet, Thick Cloth, Leather, Rubber, Plastic, Wooden Table, Glass Table, Metal Table, Wooden Table, Glass Table, Metal Table, Wooden Table, Glass Table, Metal Table