MOECEN

True Wireless Stereo Earbuds

Quick Start Guide

Contents

EN 1-12
FR 13-24
ES 25-36
PT 37-48
AR 49-60

Read this guide before using the device, and make sure it is charged or in use.

Conservez ce mode d'emploi et n'utilisez l'appareil ou ne le mettez en charge qu'après avoir lu ce guide.

Lea esta guía antes de usar el dispositivo y asegúrese de que está cargado o en uso.

Leia este guia antes de usar o aparelho e certifique-se de que está carregado ou em uso.

قم بقراءة هذا الدليل قبل استخدام الجهاز، وتأكد من شحنه أو استخدامه.

Safety Information

- Do not use the device in heavy, limited, or dirty environments or near magnetic fields, or in extreme cold or heat.
- Adjust the volume to a proper level before using headphones to avoid hearing damage.
- Do not use the device while driving or cycling to avoid accidents.
- Do not use or expose the device, or insert it with contact in any other liquids, to prevent short circuits, corrosion, or damage to electronic circuits and components.
- Keep the device away from fire to avoid explosion, such as exposure to heat, direct sunlight, or placing it near a heat source. Do not place the device in microwaves or ovens.
- Do not drop, crush, or puncture the device to avoid internal damage and overheating.
- Do not use, store, or transport the device in high temperatures or low temperatures.
- Use the device at temperatures between -10°C and 45°C and store the device at temperatures between 0°C and 45°C. Exceeding these limits may affect the battery lifespan and cause overheating.
- Do not disassemble, modify, or alter the device or cover, and avoid pressure, bending, or impact.
- Do not use the device in environments that may contain small components or cut off electrical equipment, such as medical devices, to prevent interference.
- Use only the charging cable provided or a compatible charging cable to prevent overheating and damage to the device.
- Do not touch the charging port with conductive objects (e.g., metal) to prevent short circuits.
- Do not charge the device in environments that may contain combustible or explosive substances to prevent fire or explosion.
- Do not use the device if it is damaged, deformed, or has exposed circuitry or components, and stop charging immediately.
- Do not use the device if the battery is leaking, emits odor, or overheats, and contact a professional repair center.
- Do not use the device if the charging port is damaged or corroded, and contact a professional repair center.
- Do not use the device if the charging cable is damaged, frayed, or exposed, and stop charging immediately.
- Do not use the charging cable if it is damaged or has exposed wires, and stop charging immediately.
- Do not use the charging cable if the charging port is damaged or corroded, and contact a professional repair center