


Connecting and Activating the Modem


Connecting to Yota is easy:

1. Insert the SIM card into Modem YOTA 4G LTE. The SIM card slot is located under the USB plug.
 2. Plug in your Modem YOTA 4G LTE into your computer, and it will connect to our network automatically.
 3. Register or log in at yota.ru to activate your modem.
- **Note:** If you have issues with the automatic installation of the modem in Windows XP, please run the installation manually on the "Yota" disk that appears in the "My Computer" folder.
 - **Note:** You can check the modem status at status.yota.ru.


Open the USB plug



Put the SIM card in, contacts facing down



Push the card into the slot



Yota Ready Program

Be aware that with Modem YOTA 4G LTE you can access the Internet through virtually any Yota Ready devices as well as your laptop and computer — this includes routers, gaming consoles, TVs, navigators, etc.

Look for the Yota Ready sign, plug in Modem YOTA 4G LTE, connect, sit back and enjoy wireless broadband.



Precautions

Please read these rules carefully. These will help you avoid dangerous situations and ensure fault-free operation of the modem:

- Keep the modem and its parts out of reach of small children and animals. They can suffocate trying to swallow the modem or its parts.
- The modem is designed for use in a dry, clean and well-ventilated room away from strong heat sources.
- Do not install the modem in places with high humidity.
- Do not expose the modem to very high or very low temperatures.
- Avoid getting liquids inside the modem.
- A modem is a complex electronic device. A blow or fall may cause its serious damage.
- When you move your PC, unplug the modem to prevent damage to the USB plug.
- Never open or try to repair the modem yourself. Repairs should be performed by qualified personnel only, otherwise the factory warranty will be void.

Warranty

1. The Manufacturer bears liability under the warranty for one year from the date of purchase (provided no violations of these Terms occur). The Manufacturer's warranty applies only to units intended for supply and sale in the Russian Federation, acquired in Russia and certified for compliance in Russia.
2. In order to use the warranty service from the date of the modem's sale, please save all sales receipts or other documents certifying the fact and the date of the sale, and present them when applying for the warranty service. If the date of sale cannot be identified, in accordance with Russian law on consumer rights protection, the warranty period is deemed to start from the date of a unit's manufacture.
3. If you have any problems using your modem, we strongly recommend that you contact Yota. Contact details are available in this User Manual and on yota.ru.

4. The warranty does not apply to the following shortcomings:
 - mechanical damage incurred after the modem was delivered to the consumer;
 - defect occurred due to normal wear and tear in the course of the modem's operation;
 - faults associated with exposure to computer viruses and similar programs; installation, change or deletion of the modem's passwords/codes; unauthorized use of service codes; modification and/or re-installation of the modem software/firmware and customer software; installation and/or use of counterfeit software and customer software;
 - faults caused by poor performance and/or nonconformity to standards of power supply, telecommunication and cable networks, and other external factors of this sort;
 - defects that appear due to insufficient capacity of telecommunication networks and radio signal strength, including those due to local properties of the terrain and urban environment, use of the modem at the border or outside of the network coverage area and/or compatible devices;
 - faults caused by use of non-standard and/or low-quality consumables, accessories, spare parts, batteries.

5. The warranty is void in the following cases:
 - if the serial number and/or ID have been re-written, erased or otherwise altered;
 - if it has been used in any manner other than its intended purpose and/or there has been a violation of Rules and conditions of operation and storage, set out in the documents enclosed with the modem;
 - if the modem has traces of unqualified repair attempts and/or the defect is caused by changes in design or circuitry, which were not authorized by the Manufacturer;
 - if the defect is caused by exposure to moisture, high or low temperatures, corrosion, oxidation, exposure of the internal parts to foreign objects, substances, liquids, insects, etc.;
 - if the defect is caused by an act of force majeure, accident, intentional and/or negligent action/inaction of the consumer and/or third parties.

6. Manufacturer, Importer and Seller are not liable for any damages directly or indirectly caused through the loss, alteration or unavailability of this data.
7. Manufacturer, Importer and Seller are not liable for any damage directly and/or indirectly caused by a modem to people, pets, property, if it occurred as a result of non-compliance with the Rules and conditions of operation and storage, intentional or negligent action/inaction of the consumer and/or third party.

Key Consumer Features

- A modem is intended to be used to provide Internet access via a wireless connection in 3GPP E-UTRA Rel8 standard.
- LED network indicator.
- Built-in antenna.
- The device is powered and connected via a USB plug and Micro-USB port (v. 2.0 or higher).
- Internet access software and drivers are pre-installed in the modem.
- Compatibility with the following operating systems: Windows XP SP3/Vista/7/8, OS X 10.6 and higher, Linux and others (CDC/RNDIS support required).
- Ambient operating temperature and humidity: 0...+50°C, 0-95% non-condensing.
- Dimensions: 82x28.1x12.3 mm.
- Weight: 22g.
- Service life: 1 year.

Certification

Modem YOTA 4G LTE has been tested and was found to be in compliance with Russian regulatory requirements for telecommunications and information.

Contact Details

Manufacturer
Ampak Technology (Suzhou) INC.
NO.1, Zheng Wen Road. New & High Tech Industrial Park, Changshu Economic Development Zone, Jiangsu Province, 215500, P.R.C

Developer
Yota Devices LLC, 126A, Savushkina st., 197374, Saint-Petersburg, Russia


Importer
Distribution Center LLC, 18, Vashutinskoe Shosse, 141400, Khimki, Moscow Region

Yota
Read about us at: yota.ru
Email us at: support@yota.ru
Talk to us: 8 800 700 55 00

Инструкция по подключению

Для первого подключения к Yota:

1. Установите SIM-карту в Модем YOTA 4G LTE. Разъем для SIM-карты находится под откидывающимся USB-штекером.
 2. Вставьте Модем YOTA 4G LTE в компьютер, и он автоматически подключится к сети.
 3. Активируйте модем в Личном кабинете на yota.ru.
- **Примечание:** если в Windows XP модем не установился автоматически, запустите программу установки вручную с диска Yota, появившегося в папке «Мой компьютер».
 - **Примечание:** вы можете проверить состояние подключения модема на status.yota.ru.



Программа Yota Ready

Если вы видите на игровой приставке, телевизоре, роутере или любом другом устройстве логотип Yota Ready, значит это устройство полностью готово для подключения к Yota.

Достаточно подключить к нему Модем YOTA 4G LTE, чтобы начать пользоваться мобильным интернетом Yota.



Правила эксплуатации

- Держите модем в недоступном для детей и животных месте: они могут случайно проглотить модем или его части.
- Храните и используйте модем в сухом, чистом и проветриваемом помещении.
- Не пользуйтесь модемом в местах с повышенной влажностью.
- Не подвергайте модем воздействию слишком низкой или слишком высокой температуры.
- Избегайте попадания жидкости на корпус и внутрь модема.
- Удар или падение могут привести к повреждению модема. Если вы перемещаете свой компьютер или ноутбук, отключите модем, чтобы не повредить USB-порт.
- Не пытайтесь разобрать или отремонтировать модем, иначе гарантия будет недействительна.

Гарантийные обязательства

1. Изготовитель несет гарантийные обязательства в течение 12 месяцев с даты продажи модема при соблюдении Правил эксплуатации и хранения, условий гарантии. Гарантийные обязательства распространяются только на модемы, предназначенные для продажи в Российской Федерации, приобретенные и сертифицированные в РФ.
2. Для гарантийного обслуживания с даты продажи модема необходимо сохранить товарный и кассовый чеки либо иные фискальные документы, подтверждающие факт и дату продажи. Если дату продажи установить невозможно, в соответствии с законодательством Российской Федерации гарантийный срок исчисляется с даты выпуска модема.
3. При возникновении вопросов или проблем при использовании модема просим вас обращаться в Yota. Контактная информация представлена в данном руководстве и на сайте yota.ru.

4. Гарантийные обязательства не распространяются на следующие недостатки модема:
 - механические повреждения, возникшие после передачи модема потребителю;
 - недостатки, возникшие вследствие естественного износа при эксплуатации;
 - недостатки, вызванные действием компьютерных вирусов и аналогичных им программ; установкой, сменой или удалением паролей; применением сервисных кодов, не описанных в документации пользователя; использованием неоригинального ПО модема;
 - недостатки, вызванные неудовлетворительной работой и (или) несоответствием стандартам питающих, телекоммуникационных сетей и других подобных факторов;
 - недостатки, проявляющиеся из-за особенностей рельефа местности и городской застройки, использования модема на границе или вне зоны действия сети и (или) сигнала периферийных устройств;

- недостатки, вызванные использованием нестандартных и (или) некачественных принадлежностей, запасных частей, элементов питания.
- 5. Действие гарантийных обязательств прекращается в случае:
 - если серийный номер и (или) ID модема стерт и (или) изменены;
 - если модем использовался в целях, не соответствующих его прямому назначению, а также при нарушении Правил эксплуатации и хранения;
 - если модем имеет следы попыток неквалифицированного ремонта, а также при изменении конструкции или схемы модема, не предусмотренных Изготовителем;
 - если дефект вызван воздействием влаги, высоких или низких температур, коррозией, окислением, попаданием внутрь модема посторонних предметов, веществ, жидкостей;
 - если дефект вызван воздействием неодолимой силы, несчастными случаями, умышленными и (или) неосторожными действиями (бездействием) потребителя и (или) третьих лиц.

6. Изготовитель, Импортёр и Продавец не несут ответственности за возможный вред, прямо или косвенно нанесенный утратой, изменением и (или) невозможностью использования любых данных, передаваемых с помощью модема.
7. Изготовитель, Импортёр и Продавец не несут ответственности за возможный вред, прямо и (или) косвенно нанесенный людям, домашним животным, имуществу, в случае, если это произошло в результате несоблюдения Правил эксплуатации и хранения модема, умышленных и (или) неосторожных действий (бездействия) потребителя и (или) третьих лиц.

Основные потребительские характеристики

- Данный товар предназначен для радиодоступа к сети Интернет путем беспроводной передачи данных в стандарте 3GPP E-UTRA Rel8.
- Встроенная антенна.
- Светодиодный индикатор.
- Питание и подключение через порты USB и Micro-USB (версия 2.0 и выше).
- ПО для доступа в Интернет предустановлено в память устройства.
- Системные требования: Windows XP SP3/Vista/7/8, OS X 10.6 и выше, Linux и другие с поддержкой CDC/RNDIS.
- Требуемая температура и влажность окружающего воздуха: от 0°С до +50°С, 0-95% без конденсации.
- Размеры: 82x28.1x12.3 мм.
- Вес: 22 г.
- Срок службы: 1 год.

Информация о сертификации

Модем YOTA 4G LTE был проверен и признан соответствующим требованиям законодательства РФ в области телекоммуникаций.

Контактная информация

Изготовитель
Ampak Technology (Suzhou) INC.,
NO.1, Zheng Wen Road, New & High Tech
Industrial Park, Changshu Economic
Development Zone, Jiangsu Province,
215500, P.R.C

Разработчик
ООО «Йота Девайсез», 197374,
Санкт-Петербург, ул. Савушкина,
дом 12б, лит А

Импортер
ООО «Центр дистрибуции», 141400,
Московская область, г. Химки,
Вашутинское шоссе, владение 18

Yota
Почитать о нас: yota.ru
Написать нам: support@yota.ru
Поговорить с нами: 8 800 700 55 00