

TV Wall Mount



Fixed



Download Assembly Instructions with Text

For more information: barkanmounts.com



If you are satisfied with the product, please give us a 5 stars ★★★★★ rating on the website you bought it from. If you are not satisfied please contact us at <https://www.barkanmounts.com/support> and we will solve the problem for you.



CAUTION This Mount is intended for use only with the maximum weight indicated. Using heavier products might cause injury.


Included Parts not to scale



Page 2




#	M	L mm	L inch	pcs
Z1	6	16	$5/8$	4
Z2	6	25	1	4
Z3	4	20	$3/4$	4
Z5	8	25	1	4
Z6	8	45	$1\frac{3}{4}$	4

Required Tools






1a



For more positioning options




1b




For more positioning options













2






3







4




4a




4b




The anchor must be sunk at least 3/8" / 10 mm into the plaster coating




5




6






7



8



9



10

