


TV Wall Mount

Full Motion: Rotate, Fold, Swivel & Tilt




Download Assembly Instructions with Text

For more information: barkanmounts.com


If you are satisfied with the product, please give us a 5 stars ★★★★★ rating on the website you bought it from. If you are not satisfied please contact us at <https://www.barkanmounts.com/support> and we will solve the problem for you.

2300-MAN-BNG-09_2103




CAUTION This Mount is intended for use only with the maximum weight indicated. Using heavier products might cause injury.


Included Parts not to scale




#	M	L mm	L inch	pcs
Z1	6	16	5/8	4
Z2	6	25	1	4
Z3	4	20	3/4	4
Z5	8	25	1	4
Z6	8	45	1 3/4	4

Required Tools






1





1a



1b

Page 4


1a




2

Page 5




1b



For more positioning options





2




<https://www.barkanmounts.com/faq>

3




4



X3
CONNECTION
POINTS

4a

Page 6






X3
CONNECTION
POINTS




4b

Page 6



4a





4b




The anchor must be sunk at least 3/8"/10 mm into the plaster coating




5






6




7





8



9



10



11

