


TV Wall Mount



Tilt












Download Assembly Instructions with Text

For more information: **barkanmounts.com**

If you are satisfied with the product, please give us a 5 stars ★★★★★ rating on the website you bought it from. If you are not satisfied please contact us at <https://www.barkanmounts.com/support> and we will solve the problem for you.




CAUTION This Mount is intended for use only with the maximum weight indicated. Using heavier products might cause injury.


A  x1	B  x1	C  x1
Z4  x4	Z7  x8	Z8  x1
W1  x5	W2  x5	W3  x5



#	M	L mm	L inch	pcs
Z1	6	16	5/8	4
Z2	6	25	1	4
Z3	4	20	3/4	4
Z5	8	25	1	4
Z6	8	45	1 3/4	4



Required Tools







Z7

1





1a



1b

Page 4

1a




2

Page 4

For more positioning options




1b






For more positioning options










2



3




4



4a





Page 6







4b

Page 6



4a





4b




The anchor must be sunk at least 3/8"/10 mm into the plaster coating




5




6






7




8



9



10



11

