


GETTING TO KNOW YOUR MORRO X5 PROtt

AUDIO-IN MODE

Power LED indicator is lighted solid in this mode.
Audio signal from audio-in at the rear side of the speaker system. Connect your speaker to audio device, example like PC/Notebook.




Note: When USB Flash Drive and SD/MMC card plug-in at the same time, it will detect USB Flash Drive only.

BLUETOOTH MODE

Bluetooth search name "X5"
Press "MODE" button to Bluetooth

FM MODE

FM bandwidth: 87.0 MHz ~ 108.0 MHz



EQ BUTTON

Provide up to 6 different equalizer setting [NORMAL→POP→ROCK→JAZZ→CLASSIC→COUNTRY]



Note: Equalizer setting works under USB Flash Drive and SD/MMC card MP3 file playback only.
Audio-in Mode is not able use EQ setting.

Note: Auto scan available FM channel, the strength of FM signal is depend on the received signal level within your area. Some rural areas are unlikely ever to be effectively covered.
Weak signal strength can also be caused by destructive interference of the signals from local towers in urban areas,or by the construction materials used in some buildings causing rapid attenuation of signal strength.
Large buildings such as warehouses, hospitals and factories often have no usable signal further than a few metres from the outside walls.


X5
2.1 MULTIMEDIA SPEAKER SYSTEM



USER MANUAL

IMPORTANT SAFETY INSTRUCTIONS

1. READ these instructions.
2. KEEP these instructions.
3. HEED all warnings.
- 4.FOLLOW all instructions.
5. DO NOT use this apparatus near water.
- 6.CLEAN ONLY with dry cloth.
7. DO NOT block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. DO NOT install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. UNPLUG this apparatus during lightning storms or when unused for long periods of time.



10. REFER all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged,liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

WARNING: To reduce the risk of fire or electrical shock, do not expose this product to rain or moisture. The product must not be exposed to dripping and splashing and no object filled with liquids - such as a vase of flowers - should be placed on the product.


CAUTION: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this device.

CAUTION: To prevent electric shock,match wide blade of plug to wide slot,full insert.
Stable operation at an ambient temperature within 0~40°C.

WHAT'S IN THE BOX

- 2X Satellite speaker
- 1X Subwoofer
- 1X Audio cable
- 1X User manual
- 1X Remote control

FRONT SIDE




1. Left satellite speaker
2. Subwoofer
3. Right satellite speaker
4. SD Card Input
5. USB Slot Input


6. Mode Button
7. Previous Button
8. Play/Pause Button
9. Next Button
10. Equalizer Button
11. Power LED Indicator

REMOTE CONTROL DESCRIPTION

BT | USB | SD/MMC Mode (Radio)




1. Mode Button X1
3. Volume- Button
5. >|| X1 Play/ Pause (Mute/Unmute)
7. >> X1 Next Track (Next Channel)



2. Mute Button (Switch mute mode when playing music)
4. Volume+ Button
6. |<< X1 Previous Track (Previous Channel)
8. Equalizer Button

SUBWOOFER VIEW



- 1.ON/OFF Power
2. AC Power Input
3. Volume Knob
4. Bass Knob
5. Audio Input
6. Audio Output

CONNECTING YOUR MORRO X5 PRO

