


Package Contents

Speaker x1pc
User Manual x1pc



USER MANUAL

Product Description



1. FX LED light effects
2. Volume & mode adjustment
 - ① Long press for power on / off
 - ② Short press once to switch the light mode
 - ③ Short press twice to switch Bluetooth / aux
 - ④ Turn to volume adjustment
3. 3.5mm audio jack: plug this jack into the audio output interface of your computer or laptop
4. USB jack: 5V speaker input power

Bluetooth mode

1. Long press the knob to start the machine. The default mode is aux mode. Short press for two consecutive times to switch the Bluetooth / aux mode. Then turn on the Bluetooth device of the mobile phone or computer, search the corresponding Bluetooth device and name it " V13 ", and then click Connect. After pairing and connecting, there will be a prompt tone, you can play music

2. After connecting with mobile phone once, Bluetooth has memory function. After turning on the Bluetooth of mobile phone, it can connect automatically or manually according to different types of mobile phones. If it needs to be disconnected, the Bluetooth settings can be disconnected through the mobile phone.

3. Insert aux in and press the knob twice to switch to aux mode.

Note: If the audio cable is connected to the computer or the mobile phone has current noise, please turn the audio cable head to adjust until there is no current noise.