


折线 _____



版本	制图人	日期	备注



③ A Num Lock indicator
Caps Lock indicator

- [illegible]



A diagram of a computer system. On the left is a monitor. In the center is a keyboard. On the right is a system unit (tower) with a vertical slot on its front panel. A line connects the top of the system unit to the top of the monitor, indicating a video connection. Another line connects the top of the system unit to the top of the keyboard, indicating a data connection.



- [illegible]

④ I always press the Windows key accidentally while gaming.

- [illegible]


[illegible]

- [illegible]

③ Ce périphérique est couvert par une garantie matérielle limitée 2 ans/depuis la date d'achat. Pour plus d'informations, veuillez visiter www.f3200.com.

- [illegible]

- [illegible]



5602-13A01-222 说明书75*100MM 80G铜版纸 单黑双面印刷风琴折 ESK750-98



投影符号			单位	mm
制图	卫芷晴	日期	2025.02.25	
审核		批准		

材料		物料名称	
比例	1:1	物料编号	
版本	A.1	产品编号	
共 1 张	第 1 张	图档名称	