



Manuals.plus / > Apple / > Apple Pencil (USB-C) User Manual

Apple USB-C (B0CL7DZXB2)

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

Apple Pencil (USB-C) User Manual

Model: USB-C (B0CL7DZXB2)

INTRODUCTION

The Apple Pencil (USB-C) is a versatile digital stylus designed for use with compatible iPad models. It offers pixel-perfect precision, tilt sensitivity, and low latency, making it ideal for note-taking, drawing, and document annotation. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Apple Pencil (USB-C).

WHAT'S IN THE BOX

- Apple Pencil (USB-C)

COMPATIBILITY

The Apple Pencil (USB-C) is compatible with a range of iPad models. Please refer to the list below to ensure your device is supported:

- iPad Pro 13-inch (M4)
- iPad Pro 12.9-inch (3rd, 4th, 5th, and 6th generations)

- iPad Pro 11-inch (M4)
- iPad Pro 11-inch (1st, 2nd, 3rd, and 4th generations)
- iPad Air 13-inch (M2)
- iPad Air 11-inch (M2)
- iPad Air (4th and 5th generations)
- iPad mini (A17 Pro)
- iPad mini (6th generation)
- iPad (10th generation)

SETUP

Pairing and Charging

1. **Magnetic Attachment:** Attach the Apple Pencil (USB-C) to the magnetic connector on the side of your compatible iPad. This will secure the pencil and prepare it for pairing.
2. **USB-C Connection:** Slide the cap on the Apple Pencil (USB-C) to reveal the USB-C port. Connect the Apple Pencil directly to the USB-C port on your iPad using a USB-C cable (not included with Pencil). This connection initiates both pairing and charging.
3. **Confirmation:** Once connected, a pairing request will appear on your iPad's screen. Tap "Connect" or "Pair" to complete the process. Your Apple Pencil (USB-C) is now ready for use.

Apple Pencil






Image: The Apple Pencil (USB-C) showing its hidden USB-C port, used for direct connection to an iPad for pairing and charging.

OPERATING INSTRUCTIONS

Basic Usage

- **Writing and Drawing:** Simply touch the tip of the Apple Pencil to the iPad screen to begin writing, drawing, or annotating in compatible applications.
- **Tilt Sensitivity:** The Apple Pencil responds to tilt, allowing for shading and varied line thickness, similar to a traditional pencil.
- **Low Latency:** Experience minimal delay between your hand movements and the appearance of lines on the screen, providing a natural and fluid experience.

App Integration

The Apple Pencil (USB-C) works seamlessly with built-in iPad apps like Notes and Freeform, as well as millions of other applications available on the App Store. Explore various apps to maximize your creative and productive potential.




Image: An iPad displaying a vibrant digital artwork, illustrating the Apple Pencil (USB-C) in action for creative tasks.

MAINTENANCE

- **Cleaning:** Wipe the Apple Pencil (USB-C) with a soft, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, attach the Apple Pencil (USB-C) to the magnetic side of your iPad for secure storage and to keep it charged.
- **Tip Care:** The tip of the Apple Pencil is designed for durability, but excessive force or drops can cause damage. Replacement tips may be available from Apple if needed.

TROUBLESHOOTING

Problem	Possible Solution
Apple Pencil (USB-C) not pairing.	Ensure your iPad is compatible with Apple Pencil (USB-C). Connect the Apple Pencil directly to your iPad's USB-C port. Check that Bluetooth is enabled on your iPad.

Problem	Possible Solution
	Restart your iPad.
Pencil not responding.	Check the battery level of your Apple Pencil (USB-C) by connecting it to your iPad. Ensure the tip is securely attached and not damaged. Try restarting the application you are using. Restart your iPad.
Inaccurate input or skipping.	Ensure the iPad screen is clean and free of debris. Check if the Apple Pencil tip is worn or damaged; replace if necessary. Ensure there are no strong magnetic fields nearby that could interfere.

SPECIFICATIONS

Feature	Detail
Brand	Apple
Model	USB-C
Color	White
Material	Aluminum
Dimensions (L x W x H)	15.5 x 0.7 x 0.1 centimeters
Battery Type	Lithium-ion (1 included)
Connectivity	USB-C for pairing and charging
Features	Pixel-perfect precision, tilt sensitivity, low latency, magnetic attachment

WARRANTY AND SUPPORT

The Apple Pencil (USB-C) comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the documentation included with your product or visit the official Apple support website.

For technical support, troubleshooting assistance, or service inquiries, please contact Apple Support:

- **Online Support:** Visit support.apple.com
- **Phone Support:** Check Apple's website for local contact numbers.

Return Policy: Products purchased from Amazon typically have a 30-day return/replacement policy. Please refer to your purchase details for specific return conditions.

Related Documents - USB-C (B0CL7DZXB2)

	Apple Pencil Features and Controls in Animation Pro Explore the capabilities of the Apple Pencil within Animation Pro, covering drawing controls, brush options like size, color, opacity, and force threshold, along with examples of dynamic brush effects.
	Apple Pencil Nib Replacement Guide: Easy Installation Learn how to easily replace your Apple Pencil nib with this simple guide. Get back to writing normally in seconds.
	Apple Pencil (2nd Generation) Quick Start Guide Concise guide for Apple Pencil (2nd generation) on iPad Pro, covering pairing, charging, storage, mode switching via double-tap, and tip replacement.
	Apple Pencil (2nd Generation) Quick Start Guide Concise guide for Apple Pencil (2nd generation) on pairing, charging, storing, changing modes, and replacing the tip with iPad Pro.
	Apple Pencil (მე-2 თაობა) სწრაფი დაწყება და უსაფრთხოების სახელმძღვანელო Apple Pencil (მე-2 თაობა) სწრაფი დაწყების, გამოყენებისა და უსაფრთხოების ზომების შესახებ ლაკონური სახელმძღვანელო.



AppleCare+ Conditions Générales Suisse

Conditions générales de la police d'assurance AppleCare+ pour les appareils Apple en Suisse, couvrant la réparation et le remplacement des dommages accidentels et des batteries défectueuses, ainsi que l'accès à l'assistance technique.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

APPLE USB-C (B0CL7DZXB2)

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Apple USB-C (B0CL7DZXB)

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options