




2. Installation - Windows XP


1  13:57

2  12:32 PM

3 
The 'Voice' tab is selected. The 'Device volume' section shows the volume slider set to approximately 75%. The 'Speaker settings' section shows the 'Speaker Volume...' button highlighted.

4 
The 'Voice' tab is selected. The 'Voice playback' section shows the 'Default device' set to 'Realtek AC97 Audio'. The 'Voice recording' section shows the 'Default device' set to 'Realtek AC97 Audio'. The 'Volume...' button in the 'Voice recording' section is highlighted.

5 
The 'Microphone' section is selected. The 'Volume' slider is highlighted with a red box and labeled 'A'. The 'Advanced' button is highlighted with a red box and labeled 'B'.

6 
The 'Tone Controls' section is selected. The 'Microphone Boost' checkbox is checked and highlighted with a red box and labeled 'A'. The 'Close' button is highlighted with a red box and labeled 'B'.

FAQ

Frequently asked questions

www.trust.com/17591/faq



PC Headset

MAURO | clear, digital sound | noise free speech ideal for chatting, enjoying music

© 09-09-2014 Trust International B.V. All rights reserved.

