























Power Bank
MP5000,
MP7500,
MP10000,
MP12500,
MP15000,
MP20000

Quick start guide

MP5000, MP7500, MP10000, MP12500, MP15000, MP20000

SIDE VIEW



For complete instructions and important safety information see User Guide at www.hiper-power.com