







Power Bank
RP4300,
RP5000,
RP6500,
RP7500,
RP8500,
RP10000,
RP11000,
RP12500,
RP15000,
RP20000


Quick start guide

RP4300, RP5000, RP6500, RP7500, RP8500, RP10000,
RP11000, RP12500, RP15000, RP20000



SIDE VIEW




①




②




①




②





③




④







⑤



①



②



For complete instructions and important safety information see User Guide at www.hiper-power.com