

EN Speaker Driver: 40mm, Impedance: 32 Ohms, THD <1%@1KHz, Weight: 151g. **FR** Driver Président: 40mm, Impédance: 32 Ohms, THD <1% à 1KHz, Poids: 151g. **ES** Controlador del altavoz: 40mm, Impedancia: 32 Ohms, THD <1% a 1KHz, Peso: 151g. **DE** Lautsprecher -Treiber: 40mm, Impedanz: 32 Ohm, THD <1% bei 1KHz, Gewicht: 151g. **JP** スピーカードライバー : 40ミリメートル, インピーダンス : 32オーム, THD<1%@1KHzの, 重量 : 151グラム. **ZH** 扬声器驱动器 : 40毫米, 阻抗 : 32欧姆, THD <1%@1KHz, 重量 : 151克.

EN Skullcandy, , and other marks are registered trademarks of Skullcandy, Inc. All rights reserved.
FR Skullcandy, , et les autres marques sont des marques déposées de Skullcandy, Inc. Tous droits réservés.
ES Skullcandy, , y las demás marcas son marcas registradas de Skullcandy, Inc. Todos los derechos reservados.

Americas
Skullcandy, Inc.
6301 N Landmark Dr.
Park City, UT 84098, U.S.A.
Skullcandy.com

Canada
Skullcandy Canada ULC
329 Railway St. Unit 205,
Vancouver, BC. V6A 1A4
Canada
Skullcandy.ca


Europe
Skullcandy Europe BV
Postbus 425
5500AK Veldhoven
Nederland
Skullcandy.eu

México
Skullcandy Mexico S de RL de CV
Aristoteles 218
Polanco IV Seccion, Miguel Hidalgo
11550, México City, México
Skullcandy.mx

Japan/ 日本
Skullcandy Japan 合同会社
〒150-0001 東京都渋谷区神宮前
5 - 17 - 11 パークサイドオーサキ2階
Skullcandy Japan カスタマーサービス
商品についてのお問い合わせはこちら
Skullcandy.jp

EN Made In China.
FR Fabriqué en Chine.
ES Hecho en China.
ZH 中国制造

Skullcandy.com/patent-information
© 2019 Skullcandy, Inc.
MODEL : S5PX1



OPERATION	CLICK	CLICK
TAKE/MAKE CALLS PRENDRE/PASSER APPEL ANNEHMEN/TÄTIGEN VON GESPRÄCHEN 接听/拨打电话 RECIBIR/REALIZAR LLAMADAS MODTAG/FÖRETAG ÖPKALD GESPREK AANNEHMEN/VOEREN RECEBER/FAZER CHAMADAS VASTAANOTA/SOITA PUHELU RICEVI/FAI CHIAMATE 受信/発信 전송 받기/수신 BESVAR/FÖRETA ANROP ПРИНЯТЬ ВХОДЯЩИЙ ВЫЗОВ/ПОЗВОНИТЬ TA EMOT/RING SAMTAL RECEVOIR/FAIRE DES APPELS	●	PREVIOUS TRACK PISTE PRÉCÉDENTE VORANGEHENDER TITEL 上一曲 CANCIÓN ANTERIOR FORRIGE MUSIKNUMMER VORIG NUMMER FAIXA ANTERIOR EDELLINEN KAPPALE BRANO PRECEDENTE 前のトラック 이전 트랙 FORRIGE SPOR ПРЕДЫДУЩИЙ ТРЕК FÖREGÅENDE LJUDSPÅR PISTE PRÉCÉDENTE
PLAY/PAUSE LECTURE/PAUSE WIEDERGABE/PAUSE 播放/暂停 REPRODUCIR/PAUSAR AFSPIL/PAUSE AFSPELEN/PAUZEREN REPRODUZIR/COLOCAR EM PAUSA TOISTO/TAUKO RIPRODUCI/PAUSA 재생/일시 중지 SPILL/PAUSE ВОСПРОИЗВЕДЕНИЕ/ПАУЗА SPELA UPP/PAUSA TOUCHE DE LECTURE/TOUCHE DE PAUSE	●	VOICE COMMAND (HOLD) COMMANDE VOCALE (MAINTENEZ ENFONCÉ) SPRACHBEFEHL (HALTEN) 语音命令(持续) MANDO DE VOZ(RETENER) STEMMEKOMMANDO (AT HOLDE) SPRAAKOPDRACHT (HOUDEN) COMANDO VOCAL (SEGURAR) ÄÄNIKOMENTO (PITELE) COMANDO VOCAL (TENERE) 音声命令 (ホールド) 음성 명령(과하) TALEKOMMANDO (HOLD) ГОЛОСОВОЙ КОМАНДЫ (УДЕРЖИВАТЬ) RÖSTKOMMANDO (HÅLLA UPP)
NEXT TRACK PISTE SUIVANTE NÄCHSTER TITEL 下一曲 SIGUIENTE CANCIÓN NÆSTE MUSIKNUMMER VOLGEND NUMMER FAIXA SEGUINTE SEURAAVA KAPPALE BRANO SUCCESSIVO 次のトラック 다음 트랙 NESTE SPOR СЛЕДУЮЩИЙ ТРЕК NÄSTA LJUDSPÅR PROCHAINE PISTE	● ●	