DOOGEE

User Manual

Thank for Choosing DOOGEE products

Scan to download the user manual

Scan to download the APP

Scan to follow us

Scan to join us

Scan to visit us

Scan to download the APP

Scan to follow us

Scan to join us

Scan to visit us

Get Started

Thank you for choosing DOOGEE smart phone. To ensure your safety and proper use, please read this manual carefully before using the device. Keep it for future reference.

SIM / TF Card Tray

SIM / Micro SD Card Tray

Insert the SIM card into the SIM1 card slot. If the SIM card is inserted into the SIM2 card slot, the phone will not recognize it.

Insert the Micro SD card into the TF card slot. Pay attention to the direction.

1. Select "Settings" - "Storage".
2. Select the corresponding card slot and tap "Set as portable storage" - "Next" - "Done" to complete the setup. Then you can use the TF card normally.

Insert SIM

1. Shutdown the device
2. Open the tray
3. Insert the SIM card into the corresponding slot (SIM1 or SIM2)
4. Insert the tray back into the slot
5. Turn on the device

Insert TF

1. Shutdown the device
2. Open the tray
3. Insert the TF card into the slot
4. Insert the tray back into the slot
5. Turn on the device

Voice and Ports

Volume Up Button, Volume Down Button, Power Button, Fingerprint Sensor, Microphone, Speaker, Rear Camera, Flashlight, Charging Port, Earpiece, Front Camera, Headset Port

Icons	Descriptions
Notification Panel	Swipe down from the top of the screen to open the notification panel.
Quick Settings Panel	Swipe down from the top of the screen twice to open the quick settings panel.
Home Screen	Tap the home button to return to the home screen.
Recent Apps	Tap the recent apps button to view recent apps.
Back	Tap the back button to return to the previous screen.
Screenshot	Tap the screenshot button to take a screenshot.
Lock Screen	Tap the lock screen button to lock the screen.
Flashlight	Tap the flashlight button to turn on the flashlight.
Camera	Tap the camera button to open the camera.
Volume Up	Press the volume up button to increase the volume.
Volume Down	Press the volume down button to decrease the volume.
Power	Press and hold the power button to turn on/off the device.

Lock and Unlock the Screen

Lock the Screen

1. Press the power button to turn off the screen. The screen will automatically lock after a period of inactivity.

Unlock the Screen

1. Press the power button to turn on the screen.
2. Swipe up the screen to enter the unlock interface.

Change Screen Lock

1. Select "Settings" - "Security & Privacy" - "Screen Lock" - "Screen Lock type".
2. Choose the lock screen method you prefer.

Notification Panel

Notifications include the system alerts and reports that appear in the notification panel. To open the notification panel, swipe down from the top of the screen. Tap the Settings icon to go to Settings.

Icons	Descriptions	Icons	Descriptions
Wi-Fi	Wi-Fi	Bluetooth	Bluetooth
Battery	Battery	Mobile Data	Mobile Data
Wi-Fi Hotspot	Wi-Fi Hotspot	Airplane Mode	Airplane Mode
Location	Location	Screenshot	Screenshot
Car mode	Car mode	Eye Protection	Eye Protection

Change Wallpaper

1. Select "Settings" - "Display" - "Wallpaper".
2. Choose a wallpaper from the wallpaper library or select "Wallpaper".

Set Wallpaper

1. Select "Settings" - "Display" - "Wallpaper".
2. Select "Wallpaper".
3. Select a wallpaper from the wallpaper library or select "Gallery".
4. Select "Set wallpaper".

Make a Call by Sending a Key Message

1. Select "Settings" - "Accessibility" - "Accessibility Shortcuts" - "Key message to call".
2. On the incoming call interface, drag the message icon to the specified position to send a message.

Add a Contact

1. Enter "Contacts" - tap the dialing icon to the contact interface.
2. Fill in the contact information and save.

Messaging

Text Messages

Video / Emoticons - Long-press the icon to select the emoticon or video to send.

Receive a New Message

1. When a new message is received, the notification bar will display a prompt. Tap the notification bar to open the message interface.
2. Tap the message to view the content. Tap "Delete" to delete the current message.

Telecom Interface

1. Supports dual-standby, the card slot can be hot-plug and hot-swap.
2. Ethernet card and Bluetooth settings.
3. Supports network connection sharing.
4. Supports power modes (Airplane mode, Ultra-low power consumption mode, Ultra-long standby mode, Ultra-low power mode).
5. Supports "Emergency call" - Without inserting the corresponding card, dial the emergency number (such as 112, 911, 999, 000, 08, 110, 119, 118, 120, 122, 911, 999, 112