Part Name



Product Specifications

Model Number	Item Number	Rated Voltage	Rated Frequency	Rated Power	Water Tank Capacity
HT-22/HEAT30T-RU	HEAT30T	220V~	50Hz	2200W	650ML

Executive Standard : TP TC 020/2011 , TP TC 004/2011 , TP EAC 037/2016

Product Circuit Diagram

User Manual

1.Standby Button : ⏻

In standby mode, press this button to activate the device. It will begin operating at the preset temperature of 27℃. Use the "+" and "−" keys to adjust the temperature (adjustable range: 10℃ to 35℃).

Press and hold this button for approximate 3 seconds to switch the unit to standby mode. All functions will be deactivated, and all indicator lights and displays will turn off.

2.“+”/“−”Button :

In Temperature Setting, Schedule, or Timer mode, press this button to increase/decrease the set value. This button is inactive in other modes or when the device is powered off.

3.Child Lock Button : 🔒

While the unit is on, press and hold both the "+" and "−" buttons simultaneously for 3 seconds to enable or disable the Child Lock function. During this operation, the Child Lock icon will flash. Once enabled, the icon will remain steadily lit.

4.Schedule/Timer Button : ⏲

Schedule Function: In standby mode, press this button to set a scheduled startup (default: 1 hour). Adjust the time with the "+" and "−" buttons (max: 24 hrs). Once set, other functions can be configured.
The setting sequence is as follows:

→ 1h ——→ 2h ——→ 3h ——→ ——→ 23h ——→ 24h →

Cancel Schedule

Timer Setting: While the device is operating, press this button to activate a default 1-hour auto-off timer. Use the "+" and "−" keys to adjust the duration, with a maximum setting of 24 hours. Other functions can still be configured while the timer is active.
The setting sequence is as follows:

→ 1h ——→ 2h ——→ 3h ——→ ——→ 23h ——→ 24h →

Cancel Timer

5.Setting : ⚙

Press once for high heat, twice for low heat (while powered on).

6.Screen Off Button : 🔅
(Remote Features)

Press this button while the unit is on to toggle the digital display. When the screen is off, any button press will first wake the display; a second press is required to activate the corresponding function.

7.Humidity Button : 💧

Press this button during operation to turn humidification on/off. Mist will generate after 5 seconds when activated.
WARNING: Never operate without water. Use distilled water only. Tap or mineral water will cause scale deposits, damage, and malfunctions.
WARNING: Always unplug the power cord before filling with water or cleaning.

Water Refilling Procedure

Before turning on humidification, please fill the water tank to the MAX level. The water addition method is as shown in the figure below.

If mineral deposits (scale) form on the water tank surface after prolonged use, pour dissolved descaler, citric acid, or white vinegar into the tank and let it soak. Then scrub with a cotton swab or brush, and rinse thoroughly with clean water.
Note: A slight scald and/or a mild odor during operation are normal.
Special Feature: After 24 hours of continuous operation, the device will automatically shut off and must be manually restarted to resume normal function.

Replace the humidifier wick

It is recommended to replace the humidifier wick every 4 months. However, the actual replacement interval may vary depending on usage environment and water quality.
Replacement procedure is as follows:
1.Remove the humidifier cover.
2.Gently pull down the wick cover and remove the wick.
3.Replace with a new cotton swab.
4.Reinstall it in its original position.

Safety Precautions

1. This product is designed for indoor use only. Avoid prolonged outdoor operation.
2. Water use, cleaning, and maintenance must be performed with the power unplugged. Ensure the product's nameplate, Check whether the power cord or plug is damaged. Avoid sharply bending or pulling the power cord.
3. If the heater has been stored in extreme cold below -20℃, it must be warmed to above -10℃ prior to operation. This prevents changes in material properties due to low temperatures, which could compromise product safety.
4. Always turn off the power before unplugging. Never handle the plug with wet hands to avoid the risk of electric shock.
5. If the power cord is damaged, it must be replaced by the manufacturer, its authorized service department, or similarly qualified personnel to avoid any potential hazards.
6. Use a dedicated power outlet rated for 10 amps or more.
7. This product is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. CAUTION: High surface temperatures. Keep children and vulnerable persons away from the heater. Avoid contact with the hot surfaces to prevent burns.
9. Never use the unit with compatible materials.
10. Ensure the power cord is fully unplugging or unplugging the power cord. Use the power switch for all operations.
11. Always unplug the power cord and allow the unit to cool completely before moving. When moving, handle with care and never pull or carry the unit by the power cord.
12. Never place or drape the power cord over the heater's heating fins to prevent melting and fire hazard.
13. Do not use the heater directly beneath a power outlet to prevent overheating and potential fire hazard.
14. NEVER use the heater in the immediate vicinity of a bathtub, shower, swimming pool, or any other source of water.
15. The heater must always remain in an upright position during use. Do not place or operate the unit on unstable or uneven surfaces to prevent tipping, damage, or potential hazards.
16. Do not place the heater near curtains or furniture. Maintain a minimum clearance of 50 cm from walls and furniture, and ensure at least 1 meter of unobstructed space above the unit to allow for proper air circulation.

17. DANGER: Never insert fingers, hair, or objects into openings or gaps of the unit. Extreme caution is required for children, elderly, or persons with disabilities.
18. DANGER: NEVER operate the unit in areas where flammable, explosive, or other hazardous materials are stored or used. Risk of fire, explosion, or electric shock.
19. WARNING: Do not use or store the unit in damp or dusty environments for extended periods. Humidity and dust may cause corrosion, insulation failure, and electric shock hazards.
20. WARNING: NEVER block the air inlet or outlet openings. Restricted airflow may cause overheating, performance failure, or fire.
21. DANGER: Never rinse or spray the unit with water. Do not allow water to drip into the heater grille, as this may cause electric shock or fire.
22. DANGER: Never disassemble or modify this product in any way. Unauthorized alterations may cause electric shock, fire, or void all warranties.
23. Always unplug the power cord from the electrical outlet when leaving home or not using the device for an extended period.
24. For cleaning and maintenance, always disconnect power and allow the unit to cool completely. Then clean with a damp, soft cloth or soft-bristle brush.
25. If the product malfunctions, please contact the after-sales service center. Never attempt unauthorized disassembly or repairs to avoid electric shock, fire, or voiding of warranty.
26. Avoid frequently opening or closing doors and windows during operation to maintain optimal performance.
27. During initial heating operation, slight sounds, harmless vapor, or a faint odor may occur. These are normal phenomena caused by the expansion of materials and the evaporation of protective coatings, and will disappear shortly.
28. WARNING: To prevent overheating, never cover the heater.
29. Do not use the heater directly beneath a power outlet. This prevents overheating of the electrical circuit and reduces fire risk.
30. WARNING: Always unplug the power cord before refilling water or cleaning the unit to prevent electric shock or short circuit.

Cleaning and Maintenance

① Cleaning Alert: Always unplug before cleaning!

② WARNING: Always unplug the heater and wait until completely cool before cleaning. Use only a non-abrasive damp cloth for exterior surfaces. Do not use liquid cleaners or allow moisture to enter any openings.
Gently brush the ventilation openings with a soft-bristled brush to remove dust.

③ Grease stains on the heater housing must be thoroughly cleaned to prevent discoloration or damage.

④ After cleaning and maintenance, repack all components into the original packaging box according to their original positions.

⑤ Store in a dry place.

⑥ For cleaning and maintenance, simply wipe the surface with a mild detergent solution, then follow with a dry, clean cloth to remove any residue.

⑦ Never rinse or flush the unit directly with water.

⑧ Never use thinners, toluene, acidic detergents, kerosene, alcohol, or other chemical solvents for cleaning, as they may cause discoloration or material degradation.

Heater service life: 5 years

Technical Regulation Information

Executive Standard : Conformity to national standards
TP TC 020/2011
TP TC 004/2011
TP EAC 037/2016

Troubleshooting

If the product does not operate or functions abnormally, first check the following list. If the issue persists, it may indicate product damage.
If the product malfunctions, please contact our authorized service centers or customer service department. If the issue is not listed in the table below, the product may be faulty. In such cases, it is recommended to take the product to an authorized dealer's service center for handling.

Fault Symptoms

The power indicator light does not illuminate after power-on, and the unit does not operate.
Sudden shutdown during heating

Fault Description

The plug is not fully inserted. Ensure the plug is properly seated in the outlet.
The temperature has exceeded the thermostat threshold. Allow the unit to cool down before resuming operation.

SaiJiAs Intelligent Technology (Suzhou) Limited
Address: Room 302, 3rd Floor, Building 3 No.288 Jiuzhenzuggang Road
Guosiang Street, Economic Development Zone Wuzhong District Suzhou City, Jiangsu Province, China

Production date: see carton
Terms and Conditions of Product Sale
Sales rules and conditions: No restrictions

Effective Date: V1.0
Effective Date: September 30, 2025

Contact us

Website:
https://global.dreametech.com

Welcome to use Dreame Indoor Heater.

HT-22/HEAT30T-RU

Please read this manual thoroughly before use.
Please retain this manual for future reference.

DREAME

材质：100克书纸，成品尺寸：130x185mm，折页，颜色：单色印刷

Наименование компонентов изделия


Решетка
Выход холодного воздуха
Сетка для распыления
Панель управления
HT-22/HEAT30T-RU
Воздухозаборная решетка
Таймер
Детский замок
Кнопка вкл/выкл
Кнопка выбора режима
Кнопка влажности
Кнопка «+»
Кнопка «−»
Пульт управления
Пульт ДУ
Кнопка выбора режима
Кнопка влажности
Кнопка «+»
Кнопка «−»