endever
EFFECTING IDEAS

FRYING PAN

with granite ***non-stick*** coating

AQUARELLE·261

Care and Terms of Use:

Prior the first use, please wash the cookware in a warm sud and clean with towel or napkin.

Don't use the metallic brush and cleaning abrasive dusts.

The wash in washing machine is possible.

Don't get the sudden temperature change.

Do not use the metallic kitchen implements. They leave the scratches and traces.

Friendly to wooden, nylon, silicon kitchen implements.

Don't cut the food inside the cookware.

Don't occur the overheating of the empty cookware.

Friendly to all types of plates including the induction.

Уход и правила использования:

Перед первым использованием вымойте сковороду в теплой мыльной воде и протрите мягким полотенцем или бумажной салфеткой.

Не используйте металлические щетки, а так же чистящие средства, содержащие абразив.

Допускается мытье в посудомоечной машине.

Не допускайте резкой смены температур.

Не допустимо применение металлических кухонных принадлежностей. Они оставляют следы и царапины.

Рекомендуется использовать только деревянные, нейлоновые или силиконовые кухонные принадлежности.

Не режьте пищу внутри посуды.

Не допускайте сильного перегрева пустой посуды.

Подходит для любого типа плит, включая индукционные.