



## mini optical glow mouse™

### Getting Started Guide



## English

### Hardware Installation

Simply plug the USB cable into an open USB port to begin using your mouse.

### Important Ergonomic Information

Long periods of repetitive motions using an improperly set-up workspace, incorrect body position, and poor work habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. If you feel pain, numbness, weakness, swelling, burning, cramping, or stiffness in these areas, see a qualified health professional.

### Maintenance of your Mouse

- You may clean the surface of the Mouse with a soft damp cloth.
- Do not use any harsh or abrasive cleaners.
- Before using any chemical cleaners, please test the results on the bottom of the device.

### Troubleshooting

- Try another USB port on the computer.

### Switching "Off" the Illumination

You may want to turn "off" the glow by using the "on/off" button under the mouse.

### Customer Service

If you need additional help with your product, contact Labtec on the web at: [www.labtec.com](http://www.labtec.com)

### International Standards and Safety

This optical device complies with International Standard IEC 625 1 1993 Class 1 LED Product. CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. This optical device has no serviceable parts. User observable light is 15 microwatts in normal operation. This device is rated as a commercial product for operation at 0°C to 40°C.

### Product Warranty

Labtec Hardware Product Limited Warranty. Labtec warrants that your Labtec hardware product shall be free from defects in material and workmanship for two (2) years, beginning from the date of purchase. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights, and you may also have other rights that vary under local laws.

Remedies: Labtec's entire liability and your exclusive remedy for any breach of warranty shall be, at Labtec's option, (1) to repair or replace the hardware, or (2) to refund the price paid, provided that the hardware is returned to the point of purchase, or such other place as Labtec may direct, with a copy of the sales receipt or dated itemized receipt. Shipping and handling charges may apply except where prohibited by applicable law. Labtec may, at its option, use new or refurbished or used parts in good working condition to repair or replace any hardware product. Any replacement hardware product will be warranted for the remainder of the original warranty period, or thirty (30) days, whichever is longer or for any additional period of time that may be applicable in your jurisdiction.

Limits of Warranty: This warranty does not cover problems or damage resulting from (1) accident, abuse, misapplication, or any unauthorized repair, modification or disassembly; (2) improper operation or maintenance, usage not in accordance with product instructions or connection to improper voltage supply; or (3) use of consumables, such as replacement batteries not supplied by Labtec except where such restriction is prohibited by applicable law.

How to Obtain Warranty Support: Before submitting a warranty claim, we recommend you visit the support section at [www.labtec.com](http://www.labtec.com) for technical assistance. Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after purchase; however, this period of time may vary depending on where you purchased your product. Please check with Labtec or the retailer where you purchased your product for details. Warranty claims that cannot be processed through the point of purchase and any other product related questions should be addressed directly to Labtec. The addresses and customer service contact information for Labtec can be found in the documentation accompanying your product and on the web at [www.labtec.com/contactus](http://www.labtec.com/contactus).

Limitation of Liability: LABTEC SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO, LOSS OF PROFITS, REVENUE OR DATA (WHETHER DIRECT OR INDIRECT) OR COMMERCIAL LOSS FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON YOUR PRODUCT EVEN IF LABTEC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some jurisdictions do not allow the exclusion or limitation of special, indirect, incidental, or consequential damages, so the above limitation or exclusion may not apply to you.

Duration of Implied Warranties: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS HARDWARE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY PERIOD FOR YOUR PRODUCT. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

National Statutory Rights: Consumers have legal rights under applicable national legislation governing the sale of consumer goods. Such rights are not affected by the warranties in this Limited Warranty.

No Other Warranties: No Labtec dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

Labtec Address: Labtec, Inc., 6505 Kaiser Drive, Fremont, California 94555, U.S.A.

1499 SE Tech Center Place, Suite 350,  
Vancouver, Washington 98683 [www.labtec.com](http://www.labtec.com)  
620-000151

