

Register your product and get support at [www.philips.com/welcome](http://www.philips.com/welcome)



HP8660  
HP8661  
HP8662  
HP8663  
HP8667

EN	User manual	LV	Lietuvaiš vartotojo rokas
BG	Руководство по ползването	LT	Instukcija vartotojui
CS	Průvodce pro uživatele	RO	Manual de utilizare
DE	Bedienungsanleitung	RU	Руководство по эксплуатации
HR	Korisnički priručnik	SK	Priručník uživateľa
HU	Felhasználói kézikönyv	SL	Uporabniški priročnik
KK	Қолданушының нұсқасы	SR	Korisnički priručnik
LT	Vartotojų vadovas	UK	Посібник користувача

## PHILIPS



Specifications are subject to change without notice  
© 2015 Koninklijke Philips N.V.  
All rights reserved.

## 1 Important

Read this user manual carefully before you use the appliance and keep it for future reference.

1. **WARNING:** Do not use this appliance near water.
2. When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
3. **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Always unplug the appliance after use. When the appliance overheats, it switches off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grilles to make sure they are not blocked by fluff, hair, etc.

If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

For additional protection, we advise you to install a residual current device (RCD) in the electrical circuit that supplies the bathroom. This RCD must have a rated residual operating current not higher than 30mA. Ask your installer for advice.

Do not insert metal objects into the air grilles to avoid electric shock.

Never block the air grilles.

Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.

Do not use the appliance for any other purpose than described in this manual.

Do not use the appliance on artificial hair.

When the appliance is connected to the power, never leave it unattended.

Never use any accessories or parts that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

Do not wind the mains cord round the appliance.

Wait until the appliance has cooled down before you store it.

Do not pull on the power cord after using. Always unplug the appliance by holding the plug.

Electrical safety (E) = 81dB (A)

## Electromagnetic fields (EMF)

The Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

## Environment

This symbol on a product means that the product is covered by European Directive 2012/19/EU. Inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

## 2 Before styling your hair

2.1 Always unplug the appliance and attachments cool down before you connect or disconnect the attachments.

2.2 Dry your wet hair with a clean towel first as the appliance is most effective on towel-dry hair.

2.3 Snap a suitable attachment onto the handle (E) in fig.1 with the grooves aligned (E) in fig.3.

2.4 Dry your hair with suitable airflow settings (E) in fig.1.

2.5 Select the nozzle (E) in fig.1 and attach it to the handle (E) in fig.1.

2.6 Dry your hair with suitable airflow settings (E) in fig.1.

2.7 Create loose curls (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.8 Create inward-looking hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.9 Create outward-looking hair and natural waves (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.10 Create smooth hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.11 Create wavy hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.12 Create curly hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.13 Create smooth hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.14 Create smooth hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.15 Create smooth hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.

2.16 Create smooth hair (E) in fig.1 and inform yourself about the local appliance collection system for electrical and electronic products. Follow local laws and never dispose of the product with normal household waste. Correct disposal of old products helps prevent hazardous materials for the environment and human health.



